


## CORIO2 Scaler menu - quick reference guide



\* = Also available on CV, YC & SDI Inputs.

# = Only available when selecting a PAL or NTSC output.

~ = Only available when selecting a RGB output.

+ = Only available when connecting to the A2 Audio Switcher and using at least version 132 of the firmware.