

tvONE CORIOmatrix Commands

Command-line Options

Document version 1.6.2
System API version 3.1 or later
Firmware version M310

Table of Contents

Table of Contents	1
Constraints	3
Legend	3
Top level Commands	4
CORIOmatrix Routing Commands	6
CORIOmax Commands	7
System Commands	9
System Communications Commands	13
System Security Commands	17
Resources Commands	24
Resources Configuration Commands	26
Resources EDID Commands	29
Resources Test Pattern Commands	32
Resources Resolutions Commands	33
Aliases Commands	35
Slots Commands.....	36
DVI Input Module	37
SDI Input Module	43
DVI Output Module	48
HDBaseT Output Module	57
Audio Module	68
HDBASE-T Input Module	70

Routing Commands	76
MonitorViews Commands	77
Preset Commands	79
Custom Types	81

Constraints

Note that although the tvONE system supports connections via both serial (RS-232) and Ethernet protocols, at no point does it support both connections CONCURRENTLY. The unit must be connected to just one controlling PC at any given time.

Legend

Property Name	Syntax	Type	Example	Description
Name	Command	Type	Example	Description. Used for commands that are common across all CORIOmax products.
Name	Command			Not used. This command is not currently used.

The table fields contain the following information:

Property Name	the name of the command.
Syntax	the full syntax structure of the command.
Type	the type of the value for use with this command.
Example	is an example of the command in use.
Description	a brief description of the command.

Top level Commands

Methods

Command	Syntax	Type	Example	Description
Login	Login(<username>,<password>)	Void	login(admin,adminpw) !Info : User admin Logged In	Log on to the device with the supplied username and password. For more information on the usernames and passwords see the section System Security Commands on page 17 below.

Properties

Command	Syntax	Type	Example	Description
Logout	Logout	Void	!Info : User system.security.Admin_Username Logged Out // logout	Log out the current user.
StartBatch	StartBatch	Void	!Done StartBatch	Group a number of write commands together so that they will be operated on at the same time. The effect of the commands will not be processed until the EndBatch command is received. Note that read commands will always be processed immediately.
EndBatch	EndBatch	Void	!Done EndBatch	Execute the commands entered since the last StartBatch command.
Namespaces	Namespaces	List	Aliases Slots Routing.Canvases Routing.Windows Routing.Layouts Routing.MonitorViews Resources // Namespaces	List the commands that may be omitted and the sub-command used directly. For example you may use either Slots.Slot1 or just Slot1.

Root	Root	List	root CORIOmax System Test Aliases Resources Slots Routing !Done root	List the root-level of commands. Each of these is the basis of a further group of commands, described in this document.
------	------	------	--	---

CORIOmatrix Routing Commands

It is possible to use S<n>I<n> and S<n>O<n> in place of Slot<n>.In<n> and Slot<n>.Out<n>.

Properties

Command	Syntax	Type	Example	Description
Input > Output	S<n>I<n> > S<n>O<n>	Void	S3I1 > S14O1 !Done S3I1 > S14O1	Set an input to go to an output. Audio routing depends upon the audio configuration.

CORIOmax Commands

Properties

Property Name	Syntax	Type	Example	Description
CORIOmax	CORIOmax	List	CORIOmax.Model_Name = CORIOmatrix CORIOmax.Model_Number = C3-340 CORIOmax.Serial_Number = 2218031005149 CORIOmax.Backplane_Number = 000000000000 CORIOmax.Software_Name = CORIOmatrix CORIOmax.Software_Version = V1.30600.P4 Scaling Matrix CORIOmax.RebootToMatrix() CORIOmax.Software_Date = Feb 24 2015 14:21:17 CORIOmax.Software_Update() CORIOmax.Backplane_Type = 1 !Done CORIOmax	List all of the CORIOmax commands and display the values of the properties.
Model_Name	CORIOmax.Model_Name	String	CORIOmax.Model_Name = CORIOmatrix !Done CORIOmax.Model_Name	Read-only. Get the model name for the device. e.g. CORIOmatrix or CORIOmatrix mini
Model_Number	CORIOmax.Model_Number	String	CORIOmax.Model_Number = C3-340 !Done CORIOmax.Model_Number	Read-only. Get the model number for the device. e.g. C3-510 or C3-310
Serial_Number	CORIOmax.Serial_Number	Integer	CORIOmax.Serial_Number = 2218031005149 !Done CORIOmax.Serial_Number	Read-only. Get the serial number for the device
Backplane_Number	CORIOmax.Backplane_Number	Integer	CORIOmax.Backplane_Number = 000000000000 !Done CORIOmax.Backplane_Number	Read-only. Get the serial number for the Backplane
Software_Name	CORIOmax.Software_Name	String	CORIOmax.Software_Name = CORIOmatrix !Done CORIOmax.Software_Name	Read-only. Get the name of the current firmware. e.g. CORIOmaster or CORIOmatrix
Backplane_Type	CORIOmax.BackPlane_Type			Not used.
Software_Version	CORIOmax.Software_Version	String	CORIOmax.Software_Version = V1.30600.P4 Scaling Matrix !Done CORIOmax.Software_Version	Read-only. Get the version of the current firmware

Property Name	Syntax	Type	Example	Description
Software_Date	CORIOmax.Software_Date	String	CORIOmax.Software_Date = Feb 24 2015 14:21:17 !Done CORIOmax.Software_Date	Read-only. Shows the date the software was compiled.

Methods

Method Name	Syntax	Type	Example	Description
RebootToMatrix	CORIOmax.RebootToMatrix()			Not used.
Software_Update	CORIOmax.Software_Update()	Void	Software_Update() !Done Software_Update	Initiate the firmware update process. This command assumes that the new firmware package has been copied to the SD Card first.

System Commands

Properties

Command	Syntax	Type	Example	Description
System	System	List	System.Comms = <...> System.Constraints = <...> System.Temperature_Control = <No Value> System.Security = <...> System.Menus = <...> System.Reset() System.SaveAllSettings() System.RestoreAll() System.ClearSavedSettings() System.ConfigName = NULL System.BackupToSDCard() System.RestoreBackup() System.HDCPPrintTable() System.WPrstSeqNum = 0 System.HDCPClearKeyFile() System.HDCP_Status = R System.HDCP_Debug = Off System.Status = Serving System.API_Version = 3.1.4222 System.Unit_Description = "My CORIOmatrix" System.GUI_Control = <...> System.Synclock_Inhibit = Off !Done System	List all of the System commands and display the values of the properties
Comms	System.Comms	List	System.Comms.RS232 = <...> System.Comms.Ethernet = <...> System.Comms.USB = <...> !Done System.Comms	List all of the communication properties. See System Communications Commands on page 13 below.
Constraints	System.Constraints			Not used.
Temperature_Control	System.Temperature_Control			Not used.

Command	Syntax	Type	Example	Description
Security	System.Security	List	<pre>System.Security.Guest_Username = guest System.Security.Guest_Password<Restricted> System.Security.Guest_Timeout = 300 System.Security.Guest_Role = Guest System.Security.User1_Username = user1 System.Security.User1_Password<Restricted> System.Security.User1_Timeout = 300 System.Security.User1_Role = PowerUser System.Security.User2_Username = user2 System.Security.User2_Password<Restricted> System.Security.User2_Timeout = 300 System.Security.User2_Role = User System.Security.User3_Username = user3 System.Security.User3_Password<Restricted> System.Security.User3_Timeout = 300 System.Security.User3_Role = User System.Security.User4_Username = user4 System.Security.User4_Password<Restricted> System.Security.User4_Timeout = 300 System.Security.User4_Role = User System.Security.Admin_Username = admin System.Security.Admin_Password<Restricted> System.Security.Admin_Timeout = 0 System.Security.Admin_Role = Administrator System.Security.Test_Username = test System.Security.Test_Password<Restricted> System.Security.Test_Timeout = 14400 System.Security.Test_Role = Test !Done System.Security</pre>	<p>List all of the security settings of the device.</p> <p>See System Security Commands on page 17 below.0 below</p>
Menus	System.Menus			Not used.

Command	Syntax	Type	Example	Description
ConfigName	System.ConfigName	String	System.ConfigName = Groucho !Done System.ConfigName = Groucho	Get or set the configuration name of the live system (the configuration name is a string of up to 32 characters currently without spaces). See Resources Configuration Commands on page 26 below.
WPrstSeqNum	System.WPrstSeqNum	Integer	System.WPrstSeqNum = 0 !Done System.WPrstSeqNum	Read only. Number of Routing.Preset.RestoreRead() commands executed since power on.
HDCP_Status	System.HDCP_Status			Not used.
HDCP_Debug	System.HDCP_Debug	Boolean	System.HDCP_Debug = Off !Done System.HDCP_Debug	Enable the diagnostics for the HDCP system. The output is to be captured and submitted to Tech Support for diagnosis.
Status	System.Status	SystemStatus	System.Status = Serving !Done System.Status	Read only. Get the status of the device.
API_Version	System.API_Version	String	System.API_Version = 3.1.4222 !Done System.API_Version	Read only. The version number of this API.
Unit_Description	System.Unit_Description	String	System.Unit_Description = "My CORIOmatrix" !Done System.Unit_Description	Get or set the Device Name. The device name may be no more than 32 characters in length but may contain any ASCII Extended characters including spaces (as long as string is in quotes). The value is always returned in quotes. It may be set empty by providing no characters after the "=".
GUI_Control	System.GUI_Control			Not used.
GUI_Control.First_Boot	System.GUI_Control.First_Boot			Not used.
Synclock_Inhibit	system.Synclock_Inhibit	Boolean	System.Synclock_Inhibit = Off !Done System.Synclock_Inhibit = Off	Disables the Synclock automatic display synchronisation.

Methods

Method Name	Syntax	Type	Example	Description
Reset	System.Reset()	Void	!Info: Rebooting...	Reboot the device.
SaveAllSettings	System.SaveAllSettings()	Void	//Saving settings ... //Settings saved !Done System.SaveAllSettings()	Save the current configuration to persistent memory. The device will keep these settings after a reboot.
RestoreAll	System.RestoreAll()	Void	//Loading settings ... //Settings loaded !Done System.RestoreAll()	Restore all settings Note that this command is only available from Administrator account.
ClearSavedSettings	System.ClearSavedSettings()	Void	!Done System.ClearSavedSettings()	Clear all saved settings Note that this command is only available from the Administrator account.
BackupToSDCard	System.BackupToSDCard()	Void	//Backup: File delete: //Backup: File copy:... ... //Backup: Complete !Done System.backupToSDCard()	Backup settings (including presets) to SD card.
RestoreBackup	System.RestoreBackup()	Void	// Restore: File delete: // Restore: File copy: //Restore: Complete !Done System.RestoreBackup()	Restore settings from SD card Note that this command is only available from the Administrator account.
HDCPPrintTable	System.HDCPPrintTable()	Table	system.HDCPPrintTable() [nn] Bksv cn sl ch age dp ip flags [00]89 38 AE 0D ED Y 0F 01 01 00 00000000 00000000 00000000 00000000 !Done system.HDCPPrintTable()	For diagnostic use. Prints the internal cache of HDCP keys.
HDCPClearKeyFile	System.HDCPClearKeyFile()	Void	!Done System.HDCPClearKeyFile()	Clears the internal cache of HDCP keys.

System Communications Commands

Properties

Command	Syntax	Type	Example	Description
Comms	System.Comms	List	System.Comms.RS232 = <...> System.Comms.Ethernet = <...> System.Comms.USB = <...> !Done System.Comms	List all of the communication properties
RS232	System.Comms.RS232	List	System.Comms.RS232.Baudrate = 115200 System.Comms.RS232.RS422_Mode = Off !Done System.Comms.RS232	List the current RS232 settings
RS232.Baudrate	System.Comms.RS232.Baudrate	Integer	System.Comms.RS232.Baudrate = 115200 !Done System.Comms.RS232.Baudrate	Get or set the baud rate to use. Warning changing this setting may result in loss of communication to the device!
RS232.RS422_Mode	System.Comms.RS232.RS422_Mode	Boolean	System.Comms.RS232.RS422_Mode = Off !Done System.Comms.RS232.RS422_Mode	Get or set RS422 mode.
Ethernet	System.Comms.Ethernet	List	System.Comms.Ethernet.Enabled = On System.Comms.Ethernet.MAC_Address = 00:16:9e:d7:00:10 System.Comms.Ethernet.DHCP = <...> System.Comms.Ethernet.IP_Address = 172.16.1.100 System.Comms.Ethernet.IP_Subnet_Mask = 255.255.255.0 System.Comms.Ethernet.IP_Gateway = 172.16.0.1 System.Comms.Ethernet.Command_Port = 10001 System.Comms.Ethernet.RestartEthernet() System.Comms.Ethernet.Webserver_Enabled = On !Done System.Comms.Ethernet	List the current Ethernet settings. Note that any changes will not take effect until the Ethernet is restarted (either with the command System.Comms.Ethernet.RestartEthernet() or by saving the settings and restarting the device. Warning: changing the settings may result in a loss of communication with the device.

Command	Syntax	Type	Example	Description
Ethernet.Enabled	System.Comms.Ethernet.Enabled	Boolean	System.Comms.Ethernet.Enabled = On !Done System.Comms.Ethernet.Enabled	Get or set if Ethernet communications are enabled. This setting will only take effect after restarting the Ethernet or saving the settings and rebooting. Warning: turning the Ethernet Off when connected via the Ethernet will result in a loss of communication with the device!
Ethernet.MAC_Address	System.Comms.Ethernet.MAC_Address	String	System.Comms.Ethernet.MAC_Address = 00:16:9e:d7:00:10 !Done System.Comms.Ethernet.MAC_Address	Read-only. Get the current Ethernet MAC address.
Ethernet.DHCP	System.Comms.Ethernet.DHCP	List	System.Comms.Ethernet.DHCP.Enabled = On System.Comms.Ethernet.DHCP.IP_Address = 172.16.1.100 System.Comms.Ethernet.DHCP.IP_Subnet_Mask = 255.255.255.0 System.Comms.Ethernet.DHCP.IP_Gateway = 172.16.0.1	List the current Ethernet DHCP settings.
Ethernet.DHCP.Enabled	System.Comms.Ethernet.DHCP.Enabled	Boolean	System.Comms.Ethernet.DHCP.Enabled = On !Done System.Comms.Ethernet.DHCP.Enabled	Get or set if DHCP mode is to be used for the Ethernet settings. Note that when enabled the settings in System.Comms.Ethernet.IP_Address, System.Comms.Ethernet.IP_Subnet_Mask and System.Comms.Ethernet.IP_Gateway are ignored.
Ethernet.DHCP.IP_Address	System.Comms.Ethernet.DHCP.IP_Address	String	System.Comms.Ethernet.DHCP.IP_Address System.Comms.Ethernet.DHCP.IP_Address = 172.16.1.100	Read only. Get the current Ethernet Address.
Ethernet.DHCP.IP_Subnet_Mask	System.Comms.Ethernet.DHCP.IP_Subnet_Mask	String	System.Comms.Ethernet.DHCP.IP_Subnet_Mask = 255.255.255.0 !Done System.Comms.Ethernet.DHCP.IP_Subnet_Mask	Read only. Get the current Subnet mask.

Command	Syntax	Type	Example	Description
Ethernet.DHCP.IP_Gateway	System.Comms.Ethernet.DHCP.IP_Gateway	String	System.Comms.Ethernet.DHCP.IP_Gateway = 172.16.0.1 !Done System.Comms.Ethernet.DHCP.IP_Gateway	Read only. Get the current Ethernet gateway.
Ethernet.IP_Addresses	System.Comms.Ethernet.IP_Address	String	System.Comms.Ethernet.IP_Address = 172.16.1.100 !Done System.Comms.Ethernet.IP_Address	Get or set the current Ethernet address. This setting will only take effect after restarting the Ethernet or saving the settings and rebooting. Note that if DHCP is enabled this is overridden by the settings in System.Comms.Ethernet.DHCP. Warning changing this setting may result in a loss of communication with the device.
Ethernet.IP_Subnet_Mask	System.Comms.Ethernet.IP_Subnet_Mask	String	System.Comms.Ethernet.IP_Subnet_Mask = 255.255.255.0 !Done System.Comms.Ethernet.IP_Subnet_Mask	Get or set the current Subnet mask. This setting will only take effect after restarting the Ethernet or saving the settings and rebooting. Note that if DHCP is enabled this is overridden by the settings in System.Comms.Ethernet.DHCP. Warning changing this setting may result in a loss of communication with the device.
Ethernet.IP_Gateway	System.Comms.Ethernet.IP_Gateway	String	System.Comms.Ethernet.IP_Gateway = 172.16.0.1 !Done System.Comms.Ethernet.IP_Gateway	Get or set the current Ethernet gateway. This setting will only take effect after restarting the Ethernet or saving the settings and rebooting. Note that if DHCP is enabled this is overridden by the settings in System.Comms.Ethernet.DHCP.
Ethernet.Command_Port	System.Comms.Ethernet.Command_Port	Integer	System.Comms.Ethernet.Command_Port = 10001 !Done System.Comms.Ethernet.Command_Port	Get or set the current Ethernet port. This setting will only take effect after restarting the Ethernet or saving the settings and rebooting.

Command	Syntax	Type	Example	Description
Ethernet.Websrver_Enabled	System.Comms.Ethernet.Websrver_Enabled	Boolean	System.Comms.Ethernet.Websrver_Enabled = On !Done System.Comms.Ethernet.Websrver_Enabled	Get or set if the Web UI is enabled. This setting will only take effect after restarting the Ethernet or saving the settings and rebooting. Warning: turning the Web Server Off is not recommended as it will result in the Web UI being disabled!
USB	System.Comms.USB	List	System.Comms.USB.MSD_Enabled = On !Done System.Comms.USB	Returns current USB settings
USB.MSD_Enabled	System.Comms.USB.MSD_Enabled	Boolean	System.Comms.USB.MSD_Enabled = On !Done System.Comms.USB.MSD_Enabled	Get or set if the USB Mass Storage Device is enabled. The USB MSD is used when a PC connects to the device with a USB cable. This setting will only take effect after saving the settings and rebooting.

Methods

Method Name	Syntax	Type	Example	Description
Ethernet.RestartEthernet	System.Comms.Ethernet.RestartEthernet()	Void	System.Comms.Ethernet.RestartEthernet() !Done System.Comms.Ethernet.RestartEthernet()	Updates the Ethernet to use the current settings. Warning: changing the Ethernet settings may result in a loss of communication with the device!

System Security Commands

Properties

Command	Syntax	Type	Example	Description
Guest_Username	System.Security.Guest_Username	String	System.Security.Guest_Username = guest !Done System.Security.Guest_Username	Read only. Get the guest account username. Note that this is fixed to "guest" .
Guest_Password	System.Security.Guest_Password	Void	System.Security.Guest_Password<Restricted> !Done System.Security.Guest_Password	Restricted. It is not possible to read or set the guest password. Note that this is fixed to "guestpw"
Guest_Timeout	System.Security.Guest_Timeout	Integer	System.Security.Guest_Timeout = 300 !Done System.Security.Guest_Timeout	Read only. Get the timeout period for the guest account in seconds. Note that this is fixed to 300.
Guest_Role	System.Security.Guest_Role	Role	System.Security.Guest_Role = Guest !Done System.Security.Guest_Role	Read only. Get the guest account role. Note that this is fixed to "Guest"
User1_Username	System.Security.User1_Username	String	System.Security.User1_Username = user1 !Done System.Security.User1_Username	Get or set the account username. The default is "user1" . Note that a PowerUser may change their own account Username while an Administrator may change other account Usernames.
User1_Password	System.Security.User1_Password	String	System.Security.User1_Password = user1pw System.Security.User1_Password<Restricted> !Done System.Security.User1_Password = user1pw	Write only. Set the account password. The default is "user1pw" . Note that a PowerUser may change their own account password while an Administrator may change the passwords for other accounts.

Command	Syntax	Type	Example	Description
User1_Timeout	System.Security.User1_Timeout	Integer	System.Security.User1_Timeout = 300 !Done System.Security.User1_Timeout	Get or set the account timeout in seconds. The account will be automatically logged out when the timeout expires. The default is 300 (5 minutes). Setting the timeout to 0 disables the timeout (infinite). Warning it is possible to set the timeout value so low that the system is unusable, it is recommended that values between 1 and 300 are not used.
User1_Role	System.Security.User1_Role	Role	System.Security.User1_Role = PowerUser !Done System.Security.User1_Role	Get or set the account role. The default is "PowerUser" . Note that the role may only be changed by an Administrator.
User2_Username	System.Security.User2_Username	String	System.Security.User2_Username = user2 !Done System.Security.User2_Username	Get or set the account username. The default is "User" . Note that a PowerUser may change their own account Username while an Administrator may change other account Usernames.
User2_Password	System.Security.User2_Password	String	System.Security.User2_Password = user2pw System.Security.User2_Password<Restricted> !Done System.Security.User2_Password = user2pw	Write only. Set the account password. The default password is "user2pw" . Note that a PowerUser may change their own account password while an Administrator may change the passwords for other accounts.

Command	Syntax	Type	Example	Description
User2_Timeout	System.Security.User2_Timeout	Integer	System.Security.User2_Timeout = 300 !Done System.Security.User2_Timeout	Get or set the account timeout in seconds. The account will be automatically logged out when the timeout expires. The default timeout is 300 seconds (5 minutes). Setting the timeout to 0 disables the timeout (infinite). Warning it is possible to set the timeout value so low that the system is unusable, it is recommended that values between 1 and 300 are not used.
User2_Role	System.Security.User2_Role	Role	System.Security.User2_Role = User !Done System.Security.User2_Role	Get or set the account role. The default role is "User". Note that the role may only be changed by an Administrator.
User3_Username	System.Security.User3_Username	String	System.Security.User3_Username = user3 !Done System.Security.User3_Username	Get or set the account username. The default is "User". Note that a PowerUser may change their own account Username while an Administrator may change other account Usernames.
User3_Password	System.Security.User3_Password	String	System.Security.User3_Password = user3pw System.Security.User3_Password<Restricted> !Done System.Security.User3_Password = user3pw	Write only. Set the account password. The default password is "user3pw". Note that a PowerUser may change their own account password while an Administrator may change the passwords for other accounts.

Command	Syntax	Type	Example	Description
User3_Timeout	System.Security.User3_Timeout	Integer	System.Security.User3_Timeout = 300 !Done System.Security.User3_Timeout	Get or set the account timeout in seconds. The account will be automatically logged out when the timeout expires. The default timeout is 300 seconds (5 minutes). Setting the timeout to 0 disables the timeout (infinite). Warning it is possible to set the timeout value so low that the system is unusable, it is recommended that values between 1 and 300 are not used.
User3_Role	System.Security.User3_Role	Role	System.Security.User3_Role = User !Done System.Security.User3_Role	Get or set the account role. The default role is "User". Note that the role may only be changed by an Administrator.
User4_Username	System.Security.User4_Username	String	System.Security.User4_Username = user4 !Done System.Security.User4_Username	Get or set the account username. The default is "User". Note that a PowerUser may change their own account Username while an Administrator may change other account Usernames.
User4_Password	System.Security.User4_Password	String	System.Security.User4_Password = user4pw System.Security.User4_Password<Restricted> !Done System.Security.User4_Password = user3pw	Write only. Set the account password. The default password is "user4pw". Note that a PowerUser may change their own account password while an Administrator may change the passwords for other accounts.

Command	Syntax	Type	Example	Description
User4_Timeout	System.Security.User4_Timeout	Integer	System.Security.User3_Timeout = 300 !Done System.Security.User3_Timeout	Get or set the account timeout in seconds. The account will be automatically logged out when the timeout expires. The default timeout is 300 seconds (5 minutes). Setting the timeout to 0 disables the timeout (infinite). Warning it is possible to set the timeout value so low that the system is unusable, it is recommended that values between 1 and 300 are not used.
User4_Role	System.Security.User4_Role	Role	System.Security.User3_Role = User !Done System.Security.User3_Role	Get or set the account role. The default role is "User". Note that the role may only be changed by an Administrator.
Admin_Username	System.Security.Admin_Username	String	System.Security.Admin_Username = admin !Done System.Security.Admin_Username	Get or set the account username. The default is "admin". Note that a PowerUser may change their own account Username while an Administrator may change other account Usernames.
Admin_Password	System.Security.Admin_Password	String	System.Security.Admin_Password = adminpw System.Security.Admin_Password<Restricted> !Done System.Security.Admin_Password = adminpw	Write only. Set the account password. The default password is "adminpw". Note that a PowerUser may change their own account password while an Administrator may change the passwords for other accounts.

Command	Syntax	Type	Example	Description
Admin_Timeout	System.Security.Admin_Timeout	Integer	System.Security.Admin_Timeout = 300 !Done System.Security.Admin_Timeout	Get or set the account timeout in seconds. The account will be automatically logged out when the timeout expires. The default timeout is 300 seconds (5 minutes). Setting the timeout to 0 disables the timeout (infinite). Warning it is possible to set the timeout value so low that the system is unusable, it is recommended that values between 1 and 300 are not used.
Admin_Role	System.Security.Admin_Role	Role	System.Security.Admin_Role = Administrator !Done System.Security.Admin_Role	Get or set the account role. The default role is “Administrator” . Note that the role may only be changed by an Administrator.
Test_Username	System.Security.Test_Username	String	System.Security.Test_Username = test !Done System.Security.Test_Username	Get or set the account username. The default is “test” . Note that a PowerUser may change their own account Username while an Administrator may change other account Usernames.
Test_Password	System.Security.Test_Password	String	System.Security.Test_Password = testpw System.Security.Test_Password<Restricted> !Done System.Security.Test_Password = testpw	Write only. Set the account password. The default password is “testpw” . Note that a PowerUser may change their own account password while an Administrator may change the passwords for other accounts.

Command	Syntax	Type	Example	Description
Test_Timeout	System.Security.Test_Timeout	Integer	System.Security.Test_Timeout = 14400 !Done System.Security.Test_Timeout	<p>Get or set the account timeout in seconds.</p> <p>The account will be automatically logged out when the timeout expires.</p> <p>The default timeout is 14400 seconds (4 hours).</p> <p>Setting the timeout to 0 disables the timeout (infinite).</p> <p>Warning it is possible to set the timeout value so low that the system is unusable, it is recommended that values between 1 and 300 are not used.</p>
Test_Role	System.Security.Test_Role	Role	System.Security.Test_Role = Test !Done System.Security.Test_Role	<p>Get or set the account role.</p> <p>The default role is “Test”.</p> <p>Note that the role may only be changed by an Administrator.</p>

Resources Commands

Properties

Command	Syntax	Type	Example	Description
Resources	Resources	List	Resources.ConfigList() Resources.Configs = <...> Resources.EDID = <...> Resources.TPG = <...> Resources.LOGO = <No Value> Resources.STILL = <No Value> Resources.WARP = <No Value> Resources.Resolutions = <...> !Done Resources	List all of the Resources commands and display the values of the properties
Configs	Resources.Configs	List	Resources.Configs.Config1 = <...> Resources.Configs.Config2 = <...> ... Resources.Configs.Config19 = <...> Resources.Configs.Config20 = <...> !Done Resources.Configs	List all of the configuration slots (currently 1-20). See Resources Configuration Commands on page 26 below.
EDID	Resources.EDID	List	Resources.EDID.S10I1 = <...> Resources.EDID.S10I2 = <...> Resources.EDID.S10O1 = <...> Resources.EDID.S10O2 = <...> ... Resources.EDID.S16I1 = <...> Resources.EDID.S16I2 = <...> Resources.EDID.S16O1 = <...> Resources.EDID.S16O2 = <...> Resources.EDID.S1I2 = <...> Resources.EDID.S1O2 = <...> ... Resources.EDID.S9I1 = <...> Resources.EDID.S9I2 = <...> Resources.EDID.S9O1 = <...> Resources.EDID.S9O2 = <...> !Done Resources.EDID	List every EDID for every potential input and output. Note that the order of the output starts at Slot 10 and works through to Slot 16 then starts again at Slot 1 and goes through to Slot 9. For more information see Resources EDID Commands on page 29 below.

Command	Syntax	Type	Example	Description
TPG	Resources.TPG	List	Resources.TPG.TPG1 = <...> !Done Resources.TPG	List the test pattern generator attributes. For more information see Resources Test Pattern Commands below. Note that there is only one test pattern generator (TPG1).
LOGO	Resources.LOGO			Not used.
LOGO	Resources.STILL			Not used.
WARP	Resources.WARP			Not used.
Resolutions	Resources.Resolutions	List	Resolutions.Resolution1 = <...> Resolutions.Resolution2 = <...> ... Resolutions.Resolution1000 = <...> Resolutions.Resolution1001 = <...> ... Resolutions.Resolution1008 = <...> Resolutions.Resolution1009 = <...> !Done Resolutions	List of all the supported video resolutions, including the user configurable custom resolutions. For more information see Resources Resolutions Commands on page 33 below.

Methods

Command	Syntax	Type	Example	Description
ConfigList	Resources.ConfigList()	List	Resources.ConfigList[2]=Chico Resources.ConfigList[9]=Groucho Resources.ConfigList[13]=Harpo !Done Resources.ConfigList()	List the saved configurations by name

Resources Configuration Commands

Properties

Command	Syntax	Type	Example	Description
Configs	Resources.Configs	List	Resources.Configs.Config1 = <...> Resources.Configs.Config2 = <...> ... Resources.Configs.Config19 = <...> Resources.Configs.Config20 = <...> !Done Resources.Configs	List all 20 of the configurations.
Config<number>	Resources.Configs.Config1	List	Resources.Configs.Config1.Directory = mmc:\TVONE\CONFIGS\C1 Resources.Configs.Config1.Backup() Resources.Configs.Config1.Restore() Resources.Configs.Config1.Remove() !Done Resources.Configs.Config1	List all of the commands and display the values of the properties for the specified configuration.
Directory	Resources.Configs.Config1.Directory	String	Resources.Configs.Config1.Directory = mmc:\TVONE\CONFIGS\C1 !Done Resources.Configs.Config1.Directory	Read only. Get the name and path of the configuration file for this configuration.

Methods

Command	Syntax	Type	Example	Description
Backup	Resources.Configs.Config1.Backup()	Void	<pre>// Backup: File delete: mmc:\TVONE\CONFIGS\C1\SETTINGS\SETUP_ M.TXT ... // Backup: File delete: mmc:\TVONE\CONFIGS\C1\EDID\DEFAULTS\W UXGA.EDD // Backup: File copy: nand:\TVONE\SETTINGS\SETUP_ M.TXT ... // Backup: File copy: nand:\TVONE\EDID\DEFAULTS\WUXGA.EDD // Backup: Dir made: mmc:\TVONE\CONFIGS\C1\PRESETS\U_ D1000 // Backup: Complete !Done Resources.Configs.Config1.Backup()</pre>	<p>Backup the specified configuration from NAND to SD card. This is similar to “System.BackupToSDCard()” but for this configuration only.</p>
Restore	Resources.Configs.Config1.Restore()	Void	<pre>// Restore: File delete: nand:\TVONE\SETTINGS\SETUP_ M.TXT ... // Restore: File delete: nand:\TVONE\EDID\DEFAULTS\WUXGA.EDD // Restore: File copy: mmc:\TVONE\CONFIGS\C1\SETTINGS\SETUP_ M.TXT ... // Restore: File copy: mmc:\TVONE\CONFIGS\C1\EDID\DEFAULTS\W UXGA.EDD // Restore: Complete !Done Resources.Configs.Config1.Restore()</pre>	<p>Restore the specified configuration from SD card to NAND This is similar to “System.RestoreBackup()” but for this configuration only.</p>

Command	Syntax	Type	Example	Description
Remove	Resources.Configs.Config1.Remove()	Void	<pre>// Remove: File delete: mmc:\TVONE\CONFIGS\C1\SETTINGS\SETUP_ M.TXT ... // Remove: File delete: mmc:\TVONE\CONFIGS\C1\EDID\DEFAULTS\W UXGA.EDD // Remove: Complete !Done Resources.Configs.Config1.Remove()</pre>	Remove the specified configuration from the SD card.

Resources EDID Commands

EDID methods for each possible connection in the device are accessed by slot number and input or output number.

It is possible to use EDID.S<n>I<n> in place of Resources.EDID.S<n>I<n> and EDID.S<n>O<n> in place of Resources.EDID.S<n>O<n>.

Where:

- EDID.S<n>I<n> is an input connection of the form EDID.S1I1.
- EDID.S<n>O<n> is an output connection of the form EDID.S1O1.
- EDID.S<n><X><n> is an input or an output of the form EDID.S<n>I<n> or EDID.S<n>O<n>.

Properties

Command	Syntax	Type	Example	Description
EDID.S<n><X><n>	EDID.S<n><X><n>	List	EDID.S3I1.Filename = nand:\TVONE\EDID\S3I1.EDD EDID.S3I1.EDIDVersion = 1.3 EDID.S3I1.Manufacturer = TVO EDID.S3I1.Name = TVOneCORIOmax EDID.S3I1.SerialNumber = 0 EDID.S3I1.ManufactureDate = 201310 EDID.S3I1.Width_mm = 600 EDID.S3I1.Height_mm = 450 EDID.S3I1.HorizBdr_pix = 0 EDID.S3I1.VertBdr_pix = 0 EDID.S3I1.Extensions = 1 EDID.S3I1.Resolutions() EDID.S3I1.Remove_File() !Done EDID.S3I1	Read only. List all of the EDID properties for the specified input on the specified slot. An input will always show the EDID information from the file specified in the Filename attribute.
Filename	EDID.S<n><X><n>.Filename	String	EDID.S3I1.Filename = nand:\TVONE\EDID\S3I1.EDD !Done EDID.S3I1.Filename	Read only. Get the path and filename of the EDID file currently used for this connection.
EDIDVersion	EDID.S<n><X><n>.EDIDVersion	String	EDID.S3I1.EDIDVersion = 1.3 !Done EDID.S3I1.EDIDVersion	Read only. Get the EDID software version
Manufacturer	EDID.S<n><X><n>.Manufacturer	String	EDID.S3I1.Manufacturer = TVO !Done EDID.S3I1.Manufacturer	Read only. Get the manufacturer.
Name	EDID.S<n><X><n>.Name	String	EDID.S3I1.Name = TVOneCORIOmax !Done EDID.S3I1.Name	Read only. Get the name

Command	Syntax	Type	Example	Description
SerialNumber	EDID.S<n><X><n>.SerialNumber	Integer	EDID.S3I1.SerialNumber = 0 !Done EDID.S3I1.SerialNumber	Read only. Get the serial number.
ManufactureDate	EDID.S<n><X><n>.ManufactureDate	String	EDID.S3I1.ManufactureDate = 201310 !Done EDID.S3I1.ManufactureDate	Read only. Get the manufacture date in the form YYYYWW, where YYYY is the year and WW is the week.
Width_mm	EDID.S<n><X><n>.Width_mm	Integer	EDID.S3I1.Width_mm = 600 !Done EDID.S3I1.Width_mm	Read only. Get the addressable video image size of attached display, in millimetres
Height_mm	EDID.S<n><X><n>.Height_mm	Integer	EDID.S3I1.Height_mm = 450 !Done EDID.S3I1.Height_mm	Read only. Get the addressable video image size of attached display, in millimetres
HorizBdr_pix	EDID.S<n><X><n>.HorizBdr_pix	Integer	EDID.S3I1.HorizBdr_pix = 0 !Done EDID.S3I1.HorizBdr_pix	Read only. Get the image border size of attached display, in pixels
VertBdr_pix	EDID.S<n><X><n>.VertBdr_pix	Integer	EDID.S3I1.VertBdr_pix = 0 !Done EDID.S3I1.VertBdr_pix	Read only. Get the image border size of attached display, in pixels
Extensions	EDID.S<n><X><n>.Extensions	Integer	EDID.S3I1.Extensions = 1 !Done EDID.S3I1.Extensions	Read only. Get the number of 128-byte extension blocks included in EDID.

Methods

Command	Syntax	Type	Example	Description
Resolutions	EDID.S<n><X><n>.Resolutions()	List	<pre>// EDID.S311.Resolutions() 720x400p70 640x480p60 640x480p72 800x600p56 1280x960p60 1280x1024p60 1280x800p60 1920x1080p60 1600x1000p60 1600x1200p60 1680x1050p60 1920x1200p60 1920x1200p60 1280x720p60 !Done EDID.S311.Resolutions()</pre>	<p>Read only.</p> <p>List the resolutions available for the specified connection.</p>
Remove_File	EDID.S<n><X><n>.Remove_File())	Void	<pre>EDID.S311.Remove_File() !Done EDID.S311.Remove_File()</pre>	<p>Removes the corresponding EDID file.</p> <p>Warning this removes the connection from the EDID list.</p>

Resources Test Pattern Commands

Note that only one test pattern generator (TPG1) is supported.

Properties

Command	Syntax	Type	Example	Description
TPG	Resources.TPG	List	Resources.TPG.TPG1 = <...> !Done Resources.TPG	List the test pattern generators.
TPG1	Resources.TPG.TPG1	List	Resources.TPG.TPG1 Resources.TPG.TPG1.Resolution = 1280x720p60 Resources.TPG.TPG1.Pattern = RGB_100 Resources.TPG.TPG1.Moving_Bar = Off !Done Resources.TPG.TPG1	List the test pattern attributes Resolution is 1280x720p60 but can be modified to any of the supported output resolutions. Pattern is "RGB_100" by default but can also be "Black", "8x8_Grid", "Dot", or "8x8_ChqBrd". Moving Bar is either "Off" or "On", with default value of "Off".
TPG1.Resolution	Resources.TPG.TPG1.Resolution	Resolution	Resources.TPG.TPG1.Resolution = 1280x720p60 !Done Resources.TPG.TPG1.Resolution = 1280x720p60	Get or set the resolution for the Test Pattern Generator. The resolution is set by name, see the name property in Resources Resolutions Commands on page 33 on page 33 below.
TPG1.Pattern	Resources.TPG.TPG1.Pattern	TestPattern	Resources.TPG.TPG1.Pattern = RGB_100 !Done Resources.TPG.TPG1.Pattern	Get or set the test pattern. The default value is " RGB_100 "
TPG1.Moving_Bar	Resources.TPG.TPG1.Moving_Bar	Boolean	Resources.TPG.TPG1.Moving_Bar = Off !Done Resources.TPG.TPG1.Moving_Bar	Get or set if the moving bar is enabled. The default value is Off

Resources Resolutions Commands

List of all the supported video resolutions, including the user defined Custom Resolutions.

The system resolutions are read only and numbered from 1.

The custom resolutions can be modified and are numbered from 1000.

For more information on programming Custom Resolutions see the Resolution Editor Programming Guide.

It is possible to use Resolutions in place of Resources.Resolutions.

Properties for the System (built-in) resolutions are all Read Only.

Properties for the Custom Resolutions (Resolution1000 onwards) are Read/Write except where marked as Read only.

Properties

Command	Syntax	Type	Example	Description
Resolutions	Resolutions	List	<pre>Resolutions.Resolution1 = <...> Resolutions.Resolution2 = <...> ... Resolutions.Resolution1000 = <...> Resolutions.Resolution1001 = <...> ... Resolutions.Resolution1008 = <...> Resolutions.Resolution1009 = <...> !Done Resolutions</pre>	List of all the supported video resolutions, including the user configurable custom resolutions.
Resolutions.Resolution<n>	Resolutions.Resolution<n>	List	<pre>Resolutions.Resolution1.Name = 640x480p60 Resolutions.Resolution1.Aspect = 4:3 Resolutions.Resolution1.CanFramelock = No Resolutions.Resolution1.PixelClock = 25175000 Resolutions.Resolution1.ScanType = p Resolutions.Resolution1.HActive = 640 Resolutions.Resolution1.HFrontPorch = 16 Resolutions.Resolution1.HSyncPulse = 96 Resolutions.Resolution1.HBackPorch = 48 Resolutions.Resolution1.VActive = 480 Resolutions.Resolution1.VFrontPorch = 10 Resolutions.Resolution1.VSyncPulse = 2 Resolutions.Resolution1.VBackPorch = 33 Resolutions.Resolution1.HSyncPolarity = N Resolutions.Resolution1.VSyncPolarity = N</pre>	List the properties of the specified resolution.

Command	Syntax	Type	Example	Description
			Resolutions.Resolution1.CEAID = 1 Resolutions.Resolution1.Origin = tvONE !Done Resolutions.Resolution1	
Name	Resolutions.Resolution<n>.Name	String	Resolutions.Resolution1.Name = 640x480p60 !Done Resolutions.Resolution1.Name	Get or set the name of this resolution.
Aspect	Resolutions.Resolution<n>.Aspect	AspectRatio	Resolutions.Resolution1.Aspect = 4:3 !Done Resolutions.Resolution1.Aspect	Get or set the aspect ratio of this resolution Used assist in the signal conversion when an input and the output have different aspect ratio.
CanFramelock	Resolutions.Resolution<n>.CanFramelock			Not used.
PixelClock	Resolutions.Resolution<n>.PixelClock	Integer	Resolutions.Resolution1.PixelClock = 25175000 !Done Resolutions.Resolution1.PixelClock	Get or set the speed of the Pixel Clock in pixels per second for this resolution.
ScanType	Resolutions.Resolution<n>.ScanType	ScanMode	Resolutions.Resolution1.ScanType = p !Done Resolutions.Resolution1.ScanType	Get or set the scan type for this Resolution: p Progressive. i Interlaced scan mode.
HActive	Resolutions.Resolution<n>.HActive	Integer	Resolutions.Resolution1.HActive = 640 !Done Resolutions.Resolution1.HActive	Get or set the length of the Horizontal Active Video for this resolution
HFrontPorch	Resolutions.Resolution<n>.HFrontPorch	Integer	Resolutions.Resolution1.HFrontPorch = 16 !Done Resolutions.Resolution1.HFrontPorch	Get or set the timing interval for the Horizontal Front Porch for this resolution.
HSyncPulse	Resolutions.Resolution<n>.HSyncPulse	Integer	Resolutions.Resolution1.HSyncPulse = 96 !Done Resolutions.Resolution1.HSyncPulse	Get or set the length of the Horizontal Sync Pulse for this resolution.
HBackPorch	Resolutions.Resolution<n>.HBackPorch	Integer	Resolutions.Resolution1.HBackPorch = 48 !Done Resolutions.Resolution1.HBackPorch	Get or set the timing interval for the Horizontal Back Porch for this resolution.
VActive	Resolutions.Resolution<n>.VActive	Integer	Resolutions.Resolution1.VActive = 480 !Done Resolutions.Resolution1.VActive	Get or set the length of the Vertical Active Video for this resolution
VFrontPorch	Resolutions.Resolution<n>.VFrontPorch	Integer	Resolutions.Resolution1.VFrontPorch = 10 !Done Resolutions.Resolution1.VFrontPorch	Get or set the timing interval for the Vertical Front Porch for this resolution.
VSynPulse	Resolutions.Resolution<n>.VSynPulse	Integer	Resolutions.Resolution1.VSynPulse = 2 Resolutions.Resolution1.VSynPulse = 2	Get or set the length of the Vertical Sync Pulse for this resolution.

Command	Syntax	Type	Example	Description
VBackPorch	Resolutions.Resolution<n>.VBackPorch	Integer	Resolutions.Resolution1.VBackPorch = 33 !Done Resolutions.Resolution1.VBackPorch	Get or set the timing interval for the Vertical Back Porch for this resolution.
HSyncPolarity	Resolutions.Resolution<n>.HSyncPolarity	Polarity	Resolutions.Resolution1.HSyncPolarity = N !Done Resolutions.Resolution1.HSyncPolarity	Get or set the Horizontal Sync Polarity. N = Negative P = Positive
VSynPolarity	Resolutions.Resolution<n>.VSynPolarity	Polarity	Resolutions.Resolution1.VSynPolarity = N !Done Resolutions.Resolution1.VSynPolarity	Get or set the Vertical Sync Polarity. N = Negative P = Positive
CEAID	Resolutions.Resolution<n>.CEAID	Integer	Resolutions.Resolution1.CEAID = 1 !Done Resolutions.Resolution1.CEAID	Get or set the Consumer Electronics Association Digital Television Profile as defined in CEA-861-D
Origin	Resolutions.Resolution<n>.Origin	String	Resolutions.Resolution1.Origin = tvONE !Done Resolutions.Resolution1.Origin	Get or set the origin of the Custom Resolution.

Aliases Commands

Properties

Command	Syntax	Type	Example	Description
Aliases	Aliases	List	Aliases.Preset = Routing.Preset Aliases.Windows = Routing.Windows Aliases.Canvases = Routing.Canvases Aliases.Layouts = Routing.Layouts Aliases.MonitorViews = Routing.Monitorviews Aliases.s1i1 = Slots.Slot1.In1 ... Aliases.s16o2 = Slots.Slot16.Out2 !Done Aliases	Displays defined aliases. Syntax: aliases.<alias> = <command> For example, "Preset" is an alias for "Routing.Preset" and typing "s1i1" is the same as typing "Slots.Slot1.In1".

Slots Commands

It is possible to use Slot<n> in place of Slots.Slot<n>.

Properties

Command	Syntax	Type	Example	Description
Slots	Slots	List	Slots.Slot1 = <...> Slots.Slot2 = <...> Slots.Slot3 = <...> Slots.Slot4 = NO CARD Slots.Slot5 = NO CARD Slots.Slot6 = NO CARD Slots.Slot7 = NO CARD Slots.Slot8 = NO CARD Slots.Slot9 = NO CARD Slots.Slot10 = NO CARD Slots.Slot11 = NO CARD Slots.Slot12 = NO CARD Slots.Slot13 = NO CARD Slots.Slot14 = <...> Slots.Slot15 = <...> Slots.Slot16 = <...> !Done Slots	List all of the slots and report either the slot properties if there is a card or NO CARD if not.

DVI Input Module

It is possible to use Slot<n>.In<n> and S<n>I<n> in place of Slots.Slot<n>.In<n>.

Properties

Property Name	Syntax	Type	Example	Description
Slot<n>	Slot<n>	List	Slot3.Cardtype = DVI_U 2-in Slot3.Carddata = <No Value> Slot3.In1 = <...> Slot3.In2 = <...> Slot3.PhaseRetrain() Slot3.Module_Resolutions() !Done Slot3	List all of the properties of the card in this slot or "NO CARD" if the slot is empty.
Cardtype	Slot<n>.Cardtype	CardTypeEnum	Slot3.Cardtype = DVI_U 2-in !Done Slot3.Cardtype	Read-only. Get the type of the card in this slot
CardData	Slot<n>.Carddata			Not used.
In<n>	Slot<n>.In<n>	List	Slot3.In1.FullName = In1 Slot3.In1.Status = OK Slot3.In1.Alias = s3i1 Slot3.In1.WindowList = Window1,Window2 Slot3.In1.TypeChoice = DVI Slot3.In1.AspectChoice = 4:3 Slot3.In1.Brightness = 0 Slot3.In1.Contrast = 100 Slot3.In1.ColourScale = Auto Slot3.In1.TPG = Off Slot3.In1.Set_Resolution = 640x480p60 Slot3.In1.Measured_Resolution = 640x480p60 Slot3.In1.Measured_Width = 640 Slot3.In1.Measured_Height = 480 Slot3.In1.Measured_Field_Rate = 60 Slot3.In1.Measured_VTotal = 525 Slot3.In1.Measured_Frame_ip = p Slot3.In1.EDID_Filename = s3i1.edd Slot3.In1.ForceLinkRefresh() Slot3.In1.LeftCrop = 0 Slot3.In1.RightCrop = 0	List the properties for an Input on the given Slot. Where In<n> is the input on the card.

Property Name	Syntax	Type	Example	Description
			Slot3.In1.TopCrop = 0 Slot3.In1.BottomCrop = 0 Slot3.In1.AnH_Offset = 0 Slot3.In1.AnV_Offset = 0 Slot3.In1.OnSrcLossColour = Blue Slot3.In1.HDCP_Enabled = Supported Slot3.In1.HDCP_Required = Off Slot3.In1.HDMI = Found Slot3.In1.Audio = Found Slot3.In1.AudInA = NULL Slot3.In1.AudInB = NULL Slot3.In1.AudInC = NULL Slot3.In1.AudInD = NULL Slot3.In1.AFVChoiceA = Slot3.In1.AudInA Slot3.In1.AFVChoiceB = Slot3.In1.AudInB Slot3.In1.AFVChoiceC = Slot3.In1.AudInC Slot3.In1.AFVChoiceD = Slot3.In1.AudInD Slot3.In1.View = MonitorViews.View2 Slot3.In1.ViewPosCode = 17 Slot3.In1.AudioBars = 4 Slot3.In1.PreviewVideoType = 0 Slot3.In1.Equipment = Slot3.In1.CanFramelockTo = No Slot3.In1.dll = 16 Slot3.In1.imm = Yes !Done Slot3.In1	
FullName	Slot<n>.In<n>.FullName	String	Slot3.In1.FullName = In1 !Done Slot3.In1.FullName	Read-only. Get the full name of the Window
Status	Slot<n>.In<n>.Status	StatusEnum	Slot3.In1.Status = OK !Done Slot3.In1.Status	Read-only. Get the status of the input.
Alias	Slot<n>.In<n>.Alias	String	Slot3.In1.Alias = s3i1 !Done Slot3.In1.Alias	Get or set the Alias name for this input.
WindowList	Slot<n>.In<n>.WindowList	String	Slot3.In1.WindowList = Window1 !Done Slot3.In1.WindowList	Read only. Get the window that the slot is routed to.

Property Name	Syntax	Type	Example	Description
TypeChoice	Slot<n>.In<n>.TypeChoice	TypeChoice	Slot3.In1.TypeChoice = DVI !Done Slot3.In1.TypeChoice = DVI	Get or set the type of signal encoding on the input.
AspectChoice	Slot<n>.In<n>.AspectChoice	AspectRatio	Slot3.In1.AspectChoice = 4:3 !Done Slot3.In1.AspectChoice = 4:3	Get or set the aspect ratio for this input.
Brightness	Slot<n>.In<n>.Brightness	Integer	Slot3.In1.Brightness = 0 !Done Slot3.In1.Brightness	Get or set the brightness adjustment for this input. Valid range is from -30 to 30
Contrast	Slot<n>.In<n>.Contrast	Percentage	Slot3.In1.Contrast = 100 !Done Slot3.In1.Contrast	Get or set the contrast adjustment for the Input. Valid range is from 30% to 130%
ColourScale	Slot<n>.In<n>.ColourScale	ColourScale	Slot3.In1.ColourScale = Auto !Done Slot3.In1.ColourScale	Get or set the colour scale for this input.
TPG	Slot<n>.In<n>.TPG	Boolean	Slot3.In1.TPG = TPG1 !Done Slot3.In1.TPG = TPG1	Get or set to use the internal Test Pattern Generator (TPG1) for this input. Options are "Off" or "TPG1".
Set_Resolution	Slot<n>.In<n>.Set_Resolution	Resolution	Slot3.In1.Set_Resolution = 640x480p60 !Done Slot3.In1.Set_Resolution	Read-only. Get the current resolution set for this input.
Measured_Resolution	Slot<n>.In<n>.Measured_Resolution	Resolution	Slot3.In1.Measured_Resolution = 640x480p60 !Done Slot3.In1.Measured_Resolution	Read-only. Get the resolution being read from this Input.
Measured_Width	Slot<n>.In<n>.Measured_Width	Integer	Slot3.In1.Measured_Width = 640 !Done Slot3.In1.Measured_Width	Read-only. Get the width of the resolution being read from this input.
Measured_Height	Slot<n>.In<n>.Measured_Height	Integer	Slot3.In1.Measured_Height = 480 !Done Slot3.In1.Measured_Height	Read-only. Get the measured height of the resolution being read from this input.
Measured_Field_Rate	Slot<n>.In<n>.Measured_Field_Rate	Integer	Slot3.In1.Measured_Field_Rate = 60 !Done Slot3.In1.Measured_Field_Rate	Read-only. Get the measured field rate of the resolution being read from this input.
Measured_VTotal	Slot<n>.In<n>.Measured_VTotal	Integer	Slot3.In1.Measured_VTotal = 525 !Done Slot3.In1.Measured_VTotal	Read-only. Get the measured total vertical lines of the resolution being read from this input.

Property Name	Syntax	Type	Example	Description
Measure_Frame_ip	Slot<n>.In<n>.Measure_Frame_ip	FrameType	Slot3.In1.Measured_Frame_ip = p !Done Slot3.In1.Measured_Frame_ip	Read-only. Get the measured frame type of the resolution being read from this input.
EDID_Filename	Slot<n>.In<n>.EDID_Filename	String	Slot3.In1.EDID_Filename = s3i1.edd !Done Slot3.In1.EDID_Filename	Get or set the EDID file currently being used for this input.
LeftCrop	Slot<n>.In<n>.LeftCrop	Integer	Slot3.In1.LeftCrop = 0 !Done Slot3.In1.LeftCrop	Get or set the amount of left crop to be applied to this input.
RightCrop	Slot<n>.In<n>.RightCrop	Integer	Slot3.In1.RightCrop = 0 !Done Slot3.In1.RightCrop	Get or set the amount of right crop to be applied to this input.
TopCrop	Slot<n>.In<n>.TopCrop	Integer	Slot3.In1.TopCrop = 0 !Done Slot3.In1.TopCrop	Get or set the amount of top crop to be applied to this input.
BottomCrop	Slot<n>.In<n>.BottomCrop	Integer	Slot3.In1.BottomCrop = 0 !Done Slot3.In1.BottomCrop	Get or set the amount of bottom crop to be applied to this input.
AnH_Offset	Slot<n>.In<n>.AnH_Offset	Integer	Slot3.In1.AnH_Offset = 0 !Done Slot3.In1.AnH_Offset	Not applicable to SDI cards. Adjust the horizontal position of component analog input, measured in lines. Range from -100 to 100.
AnV_Offset	Slot<n>.In<n>.AnV_Offset	Integer	Slot6.In1.AnV_Offset = 0 !Done Slot6.In1.AnV_Offset	Not applicable to SDI cards. Adjust the vertical position of component analog input, measured in lines. Range from -100 to 100.
OnSrcLossColor	Slot<n>.In<n>.OnSrcLossColor	SrcLossColor	Slot6.In1.OnSrcLossColor = Blue !Done Slot6.In1.OnSrcLossColor	Get or set the colour to be displayed when the input source is lost.
HDCP_Enabled	Slot<n>.In<n>.HDCP_Enabled	HDCPSup	Slot3.In1.HDCP_Enabled = Supported !Done Slot3.In1.HDCP_Enabled	Not applicable to SDI cards. Get or set if HDCP is enabled for this source
HDCP_Required	Slot<n>.In<n>.HDCP_Required	HDCPReq	Slot3.In1.HDCP_Required = Off !Done Slot3.In1.HDCP_Required	Not applicable to SDI cards. Read-only. Get the HDCP capability of the input source.
HDMI	Slot<n>.In<n>.HDMI	FoundNot	Slot3.In1.HDMI = Found !Done Slot3.In1.HDMI	Read-only. Get the detected HDMI status.

Property Name	Syntax	Type	Example	Description
Audio	Slot<n>.In<n>.Audio	FoundOff	Slot3.In1.Audio = Found !Done Slot3.In1.Audio	Read only. Get if audio is available for this input.
AudInA	Slot<n>.In<n>.AudInA	String	Slot3.In1.AudInA = NULL !Done Slot3.In1.AudInA	Read only. Defines the audio channel input for channel A
AudInB	Slot<n>.In<n>.AudInB	String	Slot3.In1.AudInB = NULL !Done Slot3.In1.AudInB	Defines the audio channel input for channel B
AudInC	Slot<n>.In<n>.AudInC	String	Slot3.In1.AudInC = NULL !Done Slot3.In1.AudInC	Defines the audio channel input for channel C
AudInD	Slot<n>.In<n>.AudInD	String	Slot3.In1.AudInD = NULL !Done Slot3.In1.AudInD	Defines the audio channel input for channel D
AFVChoiceA	Slot<n>.In<n>.AFVChoiceA	AudiolInput	Slot3.In1.AFVChoiceA = Slot3.In1.AudInA !Done Slot3.In1.AFVChoiceA	Get or set the audio source channel to use in Audio Follow Video mode
AFVChoiceB	Slot<n>.In<n>.AFVChoiceB	AudiolInput	Slot3.In1.AFVChoiceB = Slot3.In1.AudInB !Done Slot3.In1.AFVChoiceB	Get or set the audio source channel to use in Audio Follow Video mode
AFVChoiceC	Slot<n>.In<n>.AFVChoiceC	AudiolInput	Slot3.In1.AFVChoiceC = Slot3.In1.AudInC !Done Slot3.In1.AFVChoiceC	Get or set the audio source channel to use in Audio Follow Video mode
AFVChoiceD	Slot<n>.In<n>.AFVChoiceD	AudiolInput	Slot3.In1.AFVChoiceD = Slot3.In1.AudInD !Done Slot3.In1.AFVChoiceD	Get or set the audio source channel to use in Audio Follow Video mode
View	Slot<n>.Out<n>.View	String	Slot3.In1.View = MonitorViews.View2 !Done Slot3.In1.View	This attribute will only show when there is a Monitor Card in the system. Get or set the view to show on the Monitor Card.
ViewPosCode	Slot<n>.Out<n>.ViewPosCode	Integer	Slot3.In1.View = MonitorViews.View2 !Done Slot3.In1.View = MonitorViews.View2	This attribute will only show when there is a Monitor Card in the system. Get or set the view position for this output on the Monitor Card.
AudioBars	Slot<n>.In<n>.AudioBars	Integer	Slot3.In1.AudioBars = 4 !Done Slot3.In1.AudioBars	Get or set the number of audio bars to show on the monitorcard screen for this input. The range is 0 to the number of audio channels.
PreviewVideoType	Slot<n>.In<n>.PreviewVideoType			Not used.
Equipment	Slot<n>.In<n>.Equipment			Not used.

Property Name	Syntax	Type	Example	Description
CanFramelockTo	Slot<n>.In<n>.CanFramelockTo			Not used.

Methods

Command	Syntax	Type	Example	Description
PhaseRetrain	Slot<n>.PhaseRetrain()	void	// Module 3 phaseL; centres at 4, 5 (5). !Done Slot3.PhaseRetrain()	Initiate a Phase retrain for this slot
Module_Resolution s	Slot<n>.Module_Resolutions()	List	Slot3.Module_Resolutions() 640x480p60;4:3; 640x480p72;4:3; ... Empty1000;4:3; Empty1001;4:3; Empty1002;4:3; Empty1003;4:3; Empty1004;4:3; Empty1005;4:3; Empty1006;4:3; Empty1007;4:3; Empty1008;4:3; Empty1009;4:3; !Done Slot3.Module_Resolutions()	List all of the supported resolutions for this slot. Custom resolutions will appear at the end of the list. The list is semicolon separated.
ForceLinkRefresh	Slot<n>.In<n>.ForceLinkRefresh() ()	Void	Slot3.In1.ForceLinkRefresh() !Done Slot3.In1.ForceLinkRefresh()	Reset the connection to the source.

SDI Input Module

It is possible to use Slot<n>.In<n> and S<n>I<n> in place of Slots.Slot<n>.In<n>.

Properties

Property Name	Syntax	Type	Example	Description
Slot<n>	Slot<n>	List	Slot2.Cardtype = SDI_3G 2-in Slot2.Carddata = <No Value> Slot2.In1 = <...> Slot2.In2 = <...> Slot2.PhaseRetrain() Slot2.Module_Resolutions() !Done Slot2	List the properties of the card in this slot or "NO CARD" if the slot is empty.
Cardtype	Slot<n>.Cardtype	CardTypeEnum	Slot2.Cardtype = SDI_3G 2-in !Done Slot2.Cardtype	Read-only. Get the type of the card in this slot
CardData	Slot<n>.Carddata			Not used.
In<n>	Slot<n>.In<n>	List	Slot2.In1.FullName = In1 Slot2.In1.Status = OK Slot2.In1.Alias = s2i1 Slot2.In1.WindowList = Window1 Slot2.In1.TypeChoice = SDI Slot2.In1.AspectChoice = 4:3 Slot2.In1.Brightness = 0 Slot2.In1.Contrast = 100 Slot2.In1.ColourScale = Auto Slot2.In1.TPG = Off Slot2.In1.Set_Resolution = 1920x1080p30 Slot2.In1.Measured_Resolution = 1920x1080p30 Slot2.In1.Measured_Width = 1920 Slot2.In1.Measured_Height = 1080 Slot2.In1.Measured_Field_Rate = 30 Slot2.In1.Measured_VTotal = 1125 Slot2.In1.Measured_Frame_ip = p Slot2.In1.LeftCrop = 0 Slot2.In1.RightCrop = 0 Slot2.In1.TopCrop = 0	List the properties for an Input on the given Slot. Where <n> is the number of the input on the card.

Property Name	Syntax	Type	Example	Description
			Slot2.In1.BottomCrop = 0 Slot2.In1.OnSrcLossColour = Blue Slot2.In1.HDMI = Not_Found Slot2.In1.Audio = Off Slot2.In1.AudInA = NULL Slot2.In1.AudInB = NULL Slot2.In1.AudInC = NULL Slot2.In1.AudInD = NULL Slot2.In1.AFVChoiceA = Slot2.In1.AudInA Slot2.In1.AFVChoiceB = Slot2.In1.AudInB Slot2.In1.AFVChoiceC = Slot2.In1.AudInC Slot2.In1.AFVChoiceD = Slot2.In1.AudInD Slot2.In1.AudioBars = 4 Slot2.In1.PreviewVideoType = 0 Slot2.In1.Equipment = Slot2.In1.CanFrameLockTo = Yes !Done Slot2.In1	
FullName	Slot<n>.In<n>.FullName	String	Slot2.In1.FullName = In1 !Done Slot2.In1.FullName	Read-only. Get the full name of the Window
Status	Slot<n>.In<n>.Status	StatusEnum	Slot2.In1.Status = OK !Done Slot2.In1.Status	Read-only. Get the status of the input.
Alias	Slot<n>.In<n>.Alias	String	Slot2.In1.Alias = s2i1 !Done Slot2.In1.Alias	Get or set the Alias name for this input.
WindowList	Slot<n>.In<n>.WindowList	String	Slot2.In1.WindowList = Window1 !Done Slot2.In1.WindowList	Read only. Get the window that the slot is routed to.
TypeChoice	Slot<n>.In<n>.TypeChoice	TypeChoice	Slot2.In1.TypeChoice = SDI !Done Slot2.In1.TypeChoice	Read only. Selects the type of input.
AspectChoice	Slot<n>.In<n>.AspectChoice	AspectRatio	Slot2.In1.AspectChoice = 4:3 !Done Slot2.In1.AspectChoice	Get or set the aspect ratio for this input
Brightness	Slot<n>.In<n>.Brightness	Integer	Slot2.In1.Brightness = 0 !Done Slot2.In1.Brightness	Get or set the brightness adjustment for this input. Valid range is from -30 to 30

Property Name	Syntax	Type	Example	Description
Contrast	Slot<n>.In<n>.Contrast	Percentage	Slot2.In1.Contrast = 100 !Done Slot2.In1.Contrast	Get or set the contrast adjustment for the Input. Valid range is from 30% to 130%
ColourScale	Slot<n>.In<n>.ColourScale	ColourScale	Slot2.In1.ColourScale = Auto !Done Slot2.In1.ColourScale	Get or set the colour scale for this input.
TPG	Slot<n>.In<n>.TPG	Boolean	Slot2.In1.TPG = Off !Done Slot2.In1.TPG	Get or set to use the internal Test Pattern Generator (TPG1) for this input. Options are "Off" or "TPG1".
Set_Resolution	Slot<n>.In<n>.Set_Resolution	Resolution	Slot2.In1.Set_Resolution = 1920x1080p30 !Done Slot2.In1.Set_Resolution	Read-only. Get the current resolution set for this input.
Measured_Resolution	Slot<n>.In<n>.Measured_Resolution	Resolution	Slot2.In1.Measured_Resolution = 1920x1080p30 !Done Slot2.In1.Measured_Resolution	Read-only. Get the resolution being read from this Input.
Measured_Width	Slot<n>.In<n>.Measured_Width	Integer	Slot2.In1.Measured_Width = 1920 !Done Slot2.In1.Measured_Width	Read-only. Get the width of the resolution being read from this input.
Measured_Height	Slot<n>.In<n>.Measured_Height	Integer	Slot2.In1.Measured_Height = 1080 !Done Slot2.In1.Measured_Height	Read-only. Get the measured height of the resolution being read from this input.
Measured_Field_Rate	Slot<n>.In<n>.Measured_Field_Rate	Integer	Slot2.In1.Measured_Field_Rate = 30 !Done Slot2.In1.Measured_Field_Rate	Read-only. Get the measured field rate of the resolution being read from this input.
Measured_VTotal	Slot<n>.In<n>.Measured_VTotal	Integer	Slot2.In1.Measured_VTotal = 1125 !Done Slot2.In1.Measured_VTotal	Read-only. Get the measured total vertical lines of the resolution being read from this input.
Measure_Frame_ip	Slot<n>.In<n>.Measure_Frame_ip	FrameType	Slot2.In1.Measured_Frame_ip = p !Done Slot2.In1.Measured_Frame_ip	Read-only. Get the measured frame type of the resolution being read from this input.
LeftCrop	Slot<n>.In<n>.LeftCrop	Integer	Slot2.In1.LeftCrop = 0 !Done Slot2.In1.LeftCrop	Get or set the amount of left crop to be applied to this input.
RightCrop	Slot<n>.In<n>.RightCrop	Integer	Slot2.In1.RightCrop = 0 !Done Slot2.In1.RightCrop	Get or set the amount of right crop to be applied to this input.

Property Name	Syntax	Type	Example	Description
TopCrop	Slot<n>.In<n>.TopCrop	Integer	Slot2.In1.TopCrop = 0 !Done Slot2.In1.TopCrop	Get or set the amount of top crop to be applied to this input.
BottomCrop	Slot<n>.In<n>.BottomCrop	Integer	Slot2.In1.BottomCrop = 0 !Done Slot2.In1.BottomCrop	Get or set the amount of bottom crop to be applied to this input.
HDMI	Slot<n>.In<n>.HDMI	FoundNot	Slot2.In1.HDMI = Not_Found !Done Slot2.In1.HDMI	Read-only. Get the detected HDMI status.
Audio	Slot<n>.In<n>.Audio	FoundOff	Slot2.In1.Audio = Off !Done Slot2.In1.Audio	Read only. Get if audio is available for this input.
AudInA	Slot<n>.In<n>.AudInA	String	Slot2.In1.AudInA = NULL !Done Slot2.In1.AudInA	Read only. Defines the audio channel input for channel A
AudInB	Slot<n>.In<n>.AudInB	String	Slot2.In1.AudInB = NULL !Done Slot2.In1.AudInB	Defines the audio channel input for channel B
AudInC	Slot<n>.In<n>.AudInC	String	Slot2.In1.AudInC = NULL !Done Slot2.In1.AudInC	Defines the audio channel input for channel C
AudInD	Slot<n>.In<n>.AudInD	String	Slot2.In1.AudInD = NULL !Done Slot2.In1.AudInD	Defines the audio channel input for channel D
AFVChoiceA	Slot<n>.In<n>.AFVChoiceA	AudioInput	Slot2.In1.AFVChoiceA = Slot2.In1.AudInA !Done Slot2.In1.AFVChoiceA	Get or set the audio source channel to use in Audio Follow Video mode
AFVChoiceB	Slot<n>.In<n>.AFVChoiceB	AudioInput	Slot2.In1.AFVChoiceB = Slot2.In1.AudInB !Done Slot2.In1.AFVChoiceB	Get or set the audio source channel to use in Audio Follow Video mode
AFVChoiceC	Slot<n>.In<n>.AFVChoiceC	AudioInput	Slot2.In1.AFVChoiceC = Slot2.In1.AudInC !Done Slot2.In1.AFVChoiceC	Get or set the audio source channel to use in Audio Follow Video mode
AFVChoiceD	Slot<n>.In<n>.AFVChoiceD	AudioInput	Slot2.In1.AFVChoiceD = Slot2.In1.AudInD !Done Slot2.In1.AFVChoiceD	Get or set the audio source channel to use in Audio Follow Video mode
AudioBars	Slot<n>.In<n>.AudioBars	Integer	Slot2.In1.AudioBars = 4 !Done Slot2.In1.AudioBars	Get or set the number of audio bars to show on the monitorcard screen for this input. The range is 0 to the number of audio channels.
PreviewVideoType	Slot<n>.In<n>.PreviewVideoType			Not used.
Equipment	Slot<n>.In<n>.Equipment			Not used.
CanFramelockTo	Slot<n>.In<n>.CanFramelockTo			Not used.

Methods

Command	Syntax	Type	Example	Description
PhaseRetrain	Slot<n>.PhaseRetrain()	void	// Module 2 phase -----L:.....:-----, centres at 15, 15 (15). !Done Slot2.PhaseRetrain()	Initiate a Phase retrain for this slot
Module_Resolutions	Slot<n>.Module_Resolutions()	List	720x487i59.94;4:3; 720x576i50;4:3; 1280x720p23.98;16:9; 1280x720p24;16:9; 1280x720p25;16:9; 1280x720p29.97;16:9; 1280x720p30;16:9; 1280x720p50;16:9; 1280x720p59.94;16:9; 1280x720p60;16:9; 1920x1080i50;16:9; 1920x1080i59.94;16:9; 1920x1080i60;16:9; 1920x1080p23.98;16:9; 1920x1080p24;16:9; 1920x1080p25;16:9; 1920x1080p29.97;16:9; 1920x1080p30;16:9; 1920x1080p50;16:9; 1920x1080p59.94;16:9; 1920x1080p60;16:9; !Done Slot2.Module_Resolutions()	List all of the supported resolutions for this slot. The list is semicolon separated. Note that custom resolutions may not be used and will not appear.

DVI Output Module

It is possible to use Slot<n>.Out<n> and S<n>O<n> in place of Slots.Slot<n>.Out<n>.

Properties

Property Name	Syntax	Type	Example	Description
Slot<n>	Slot<n>	List	Slot14.Cardtype = DVI_U 2-out Slot14.Carddata = <No Value> Slot14.Out1 = <...> Slot14.Out2 = <...> Slot14.PhaseRetrain() Slot14.Module_Resolutions() Slot14.Resolutions = <...> !Done Slot14	List the properties of the card in this slot or "NO CARD" if the slot is empty.
Cardtype	Slot<n>.Cardtype	CardTypeEnum	Slot14.Cardtype = DVI_U 2-out !Done Slot14.Cardtype	Read-only. Get the type of the card in this slot
CardData	Slot<n>.Carddata			Not used.
Out<n>	Slot<n>.Out<n>	List	Slot14.Out1.FullName = Out1 Slot14.Out1.Status = UNKNOWN Slot14.Out1.Alias = s14o1 Slot14.Out1.AspectChoice = 4:3 Slot14.Out1.DisplayType = Monitor Slot14.Out1.Resolution = 1280x720p60 Slot14.Out1.DefaultLoRes = 720x576i50 Slot14.Out1.Width = 1280 Slot14.Out1.Height = 720 Slot14.Out1.Field_Rate = 60.00 Slot14.Out1.Frame_ip = p Slot14.Out1.AnalogType = RGBHV Slot14.Out1.ColourScale = Auto Slot14.Out1.GenlockSource = NULL Slot14.Out1.Genlock = Off Slot14.Out1.RawMatrixSwitch = Off Slot14.Out1.Audio = Off Slot14.Out1.AudOutA = NULL Slot14.Out1.AudOutB = NULL Slot14.Out1.AudOutC = NULL	List the properties for an Output on the given Slot. Where Out<n> is the output on the card.

Property Name	Syntax	Type	Example	Description
			Slot14.Out1.AudOutD = NULL Slot14.Out1.ForceLinkRefresh() Slot14.Out1.HDCP_Active = Off Slot14.Out1.HDCP_Downstream = HoldOn Slot14.Out1.HDMI = Not_Found Slot14.Out1.Layout = Layout3 Slot14.Out1.WidthInLayout = 1024 Slot14.Out1.HeightInLayout = 768 Slot14.Out1.LayoutXCentre = 0 Slot14.Out1.LayoutYCentre = 0 Slot14.Out1.RotateOutDeg = 0 Slot14.Out1.HFlip = Off Slot14.Out1.VFlip = Off Slot14.Out1.GammaRed = 1 Slot14.Out1.GammaGreen = 1 Slot14.Out1.GammaBlue = 1 Slot14.Out1.SCurve = 1 Slot14.Out1.EdgeBlend_Mode = Off Slot14.Out1.OuterGrid = Off Slot14.Out1.InnerGrid = Off Slot14.Out1.LeftOverlap = 80 Slot14.Out1.RightOverlap = 80 Slot14.Out1.TopOverlap = 80 Slot14.Out1.BottomOverlap = 80 Slot14.Out1.LeftEBPos = -511 Slot14.Out1.RightEBPos = 511 Slot14.Out1.TopEBPos = -383 Slot14.Out1.BottomEBPos = 383 Slot14.Out1.Centre_BB = 0 Slot14.Out1.Left_BB = 0 Slot14.Out1.Right_BB = 0 Slot14.Out1.Top_BB = 0 Slot14.Out1.Bottom_BB = 0 Slot14.Out1.ProjectorWidthDeg = 30 Slot14.Out1.ProjectorHeightDeg = 30	

Property Name	Syntax	Type	Example	Description
			Slot14.Out1.KeystoneXDeg = 0 Slot14.Out1.KeystoneYDeg = 0 Slot14.Out1.WarpTable_Filename = Slot14.Out1.WarpTable = 0 Slot14.Out1.EDID_Filename = Slot14.Out1.View = MonitorViews.View4 Slot14.Out1.ViewPosCode = 17 Slot14.Out1.AudioBars = 4 Slot14.Out1.Equipment = Slot14.Out1.PhysicalCenterX = 0 Slot14.Out1.PhysicalCenterY = 0 Slot14.Out1.PhysicalWidth = 0 Slot14.Out1.PhysicalHeight = 0 Slot14.Out1.PhysicalPixelWidth = 0 Slot14.Out1.PhysicalPixelHeight = 0 Slot14.Out1.PhysicalBezelTop = 0 Slot14.Out1.PhysicalBezelBottom = 0 Slot14.Out1.PhysicalBezelLeft = 0 Slot14.Out1.PhysicalBezelRight = 0 Slot14.Out1.InsList = Slot3.In1 Slot14.Out1.CutToBlack = Off !Done Slot14.Out1	
FullName	Slot<n>.Out<n>.FullName	String	Slot14.Out2.FullName = Out2 !Done Slot14.Out2.FullName	Read-only. Get the full name of the Window.
Status	Slot<n>.Out<n>.Status	StatusEnum	Slot14.Out2.Status = UNKNOWN !Done Slot14.Out2.Status	Read-only. Get the status of the output.
Alias	Slot<n>.Out<n>.Alias	String	Slot14.Out2.Alias = s14o2 !Done Slot14.Out2.Alias	Get or set the Alias name for this output.
AspectChoice	Slot<n>.Out<n>.AspectChoice	AspectRatio	Slot14.Out2.AspectChoice = 4:3 !Done Slot14.Out2.AspectChoice = 4:3	Get or set the aspect ratio for this output.
DisplayType	Slot<n>.Out<n>.DisplayType	DisplayType	Slot14.Out2.DisplayType = Monitor !Done Slot14.Out2.DisplayType	Get or set the type of display connected to this output.

Property Name	Syntax	Type	Example	Description
Resolution	Slot<n>.Out<n>.Resolution	Resolution	Slot14.Out2.Resolution = 1280x720p60 !Done Slot14.Out2.Resolution	Get or set the resolution to use on this output. This must be the name of a valid resolution. See Resources Resolutions on page 33 above.
DefaultLoRes	Slot<n>.Out<n>.DefaultLoRes	Resolution	Slot14.Out2.Resolution = 1280x720p60 !Done Slot14.Out2.Resolution	Get or set the resolution to use on this output when HDCP is requested by the source but the display failed HDCP negotiation. This must be the name of a valid resolution. See Resources Resolutions on page 33 above.
Width	Slot<n>.Out<n>.Width	Integer	Slot14.Out2.Width = 1280 !Done Slot14.Out2.Width	Read-only. Get the width of this output based on the select resolution.
Height	Slot<n>.Out<n>.Height	Integer	Slot14.Out2.Height Slot14.Out2.Height = 720	Read-only. Get the height of this output based on the select resolution.
Field_Rate	Slot<n>.Out<n>.Field_Rate	String	Slot14.Out2.Field_Rate Slot14.Out2.Field_Rate = 60.00	Read-only. Get the field rate for this output based on the select resolution.
Frame_ip	Slot<n>.Out<n>.Frame_ip	FrameType	Slot14.Out2.Frame_ip = p !Done Slot14.Out2.Frame_ip	Read-only. Get the frame type for this output based on the select resolution.
AnalogType	Slot<n>.Out<n>.AnalogType	AnalogType	Slot14.Out2.AnalogType = RGBHV !Done Slot14.Out2.AnalogType	Get or set the type of analog signal to use on this output.
ColourScale	Slot<n>.Out<n>.ColourScale	ColourScale	Slot14.Out2.ColourScale = Auto !Done Slot14.Out2.ColourScale	Get or set the color scale to use on this output..
GenlockSource	Slot<n>.Out<n>.GenlockSource	Input	Slot14.Out2.GenlockSource = NULL !Done Slot14.Out2.GenlockSource	Get or set the Input to be used as the genlock source for the Output. If no Genlock is to be use then the value is to be NULL.
Genlock	Slot<n>.Out<n>.Genlock	GenlockStat us	Slot14.Out2.Genlock = Off !Done Slot14.Out2.Genlock	Read-only. Get the status of genlock for this output.

Property Name	Syntax	Type	Example	Description
RawMatrixSwitch	Slot<n>.Out<n>.RawMatrixSwitch	Boolean	Slot14.Out2.RawMatrixSwitch = Off !Done Slot14.Out2.RawMatrixSwitch	Get or set the input switching mode: Off = fade though black On = freeze and cut
Audio	Slot<n>.Out<n>.Audio	FoundOff	Slot14.Out2.Audio = Off !Done Slot14.Out2.Audio	Read only. Get if audio is available for this input.
AudOutA	Slot<n>.Out<n>.AudOutA	String	Slot14.Out2.AudOutA = NULL !Done Slot14.Out2.AudOutA	Read only. Defines the audio channel output for channel A
AudOutB	Slot<n>.Out<n>.AudOutB	String	Slot14.Out2.AudOutB = NULL !Done Slot14.Out2.AudOutB	Defines the audio channel output for channel B
AudOutC	Slot<n>.Out<n>.AudOutC	String	Slot14.Out2.AudOutC = NULL !Done Slot14.Out2.AudOutC	Defines the audio channel output for channel C
AudOutD	Slot<n>.Out<n>.AudOutD	String	Slot14.Out2.AudOutD = NULL !Done Slot14.Out2.AudOutD	Defines the audio channel output for channel D
HDCP_Active	Slot<n>.Out<n>.HDCP_Active	Boolean	Slot14.Out2.HDCP_Active = Active !Done Slot14.Out2.HDCP_Active	Read only. Get the HDCP status of this output.
HDCP_Downstream	Slot<n>.Out<n>.HDCP_Downstream	HDCPDownstream	Slot14.Out2.HDCP_Downstream = HoldOn !Done Slot14.Out2.HDCP_Downstream	Get or set the downstream HDCP mode.
HDMI	Slot<n>.Out<n>.HDMI	FoundNot	Slot14.Out2.HDMI = Found !Done Slot14.Out2.HDMI	Read-only. Get the detected HDMI status.
Layout	Slot<n>.Out<n>.Layout			Not used.
WidthInLayout	Slot<n>.Out<n>.WidthInLayout			Not used.
HeightInLayout	Slot<n>.Out<n>.HeightInLayout			Not used.
LayoutXCentre	Slot<n>.Out<n>.LayoutXCentre			Not used.
LayoutYCentre	Slot<n>.Out<n>.LayoutYCentre			Not used.
RotateOutDeg	Slot<n>.Out<n>.RotateOutDeg			Not used.
HFlip	Slot<n>.Out<n>.HFlip			Not used.
VFlip	Slot<n>.Out<n>.VFlip			Not used.
GammaRed	Slot<n>.Out<n>.GammaRed	Number	Slot14.Out1.GammaRed = 1 !Done Slot14.Out1.GammaRed	Get or set the red gamma value for this output Range: 0.30 to 2.00
GammaGreen	Slot<n>.Out<n>.GammaGreen	Number	Slot14.Out1.GammaGreen = 1 !Done Slot14.Out1.GammaGreen	Get or set the green gamma value for this output Range: 0.30 to 2.00

Property Name	Syntax	Type	Example	Description
GammaBlue	Slot<n>.Out<n>.GammaBlue	Number	Slot14.Out1.GammaBlue = 1 !Done Slot14.Out1.GammaBlue	Get or set the blue gamma value for this output Range: 0.30 to 2.00
SCurve	Slot<n>.Out<n>.SCurve	Number	Slot14.Out1.SCurve = 1 !Done Slot14.Out1.SCurve	Get or set the SCurve value for this output. (brightness curve) Range: 0.30 to 2.00
EdgeBlend_Mode	Slot<n>.Out<n>.EdgeBlend_Mode			Not used.
OuterGrid	Slot<n>.Out<n>.OuterGrid			Not used.
InnerGrid	Slot<n>.Out<n>.InnerGrid			Not used.
LeftOverlap	Slot<n>.Out<n>.LeftOverlap			Not used.
RightOverlap	Slot<n>.Out<n>.RightOverlap			Not used.
TopOverlap	Slot<n>.Out<n>.TopOverlap			Not used.
BottomOverlap	Slot<n>.Out<n>.BottomOverlap			Not used.
LeftEBPos	Slot<n>.Out<n>.LeftEBPos			Not used.
RightEBPos	Slot<n>.Out<n>.RightEBPos			Not used.
TopEBPos	Slot<n>.Out<n>.TopEBPos			Not used.
BottomEBPos	Slot<n>.Out<n>.BottomEBPos			Not used.
Centre_BB	Slot<n>.Out<n>.Centre_BB			Not used.
Left_BB	Slot<n>.Out<n>.Left_BB			Not used.
Right_BB	Slot<n>.Out<n>.Right_BB			Not used.
Top_BB	Slot<n>.Out<n>.Top_BB			Not used.
Bottom_BB	Slot<n>.Out<n>.Bottom_BB			Not used.
ProjectorWidthDeg	Slot<n>.Out<n>.ProjectorWidthDeg			Not used.
ProjectorHeightDeg	Slot<n>.Out<n>.ProjectorHeightDeg			Not used.
KeystoneXDeg	Slot<n>.Out<n>.KeystoneXDeg			Not used.
KeystoneYDeg	Slot<n>.Out<n>.KeystoneYDeg			Not used.
WarpTable_Filename	Slot<n>.Out<n>.WarpTable_Filename			Not used.
WarpTable	Slot<n>.Out<n>.WarpTable			Not used.
EDID_Filename	Slot<n>.Out<n>.EDID_Filename	String	Slot14.Out1.EDID_Filename = !Done Slot14.Out1.EDID_Filename	Get or set the EDID file in any currently being used for this output.

Property Name	Syntax	Type	Example	Description
View	Slot<n>.Out<n>.View	String	Slot14.Out1.View = MonitorViews.View4 !Done Slot14.Out1.View = MonitorViews.View4	Get or set the view to show on the Monitor Card. This attribute will only show when there is a Monitor Card in the system.
ViewPosCode	Slot<n>.Out<n>.ViewPosCode	Integer	Slot14.Out1.ViewPosCode = 17 !Done Slot14.Out1.ViewPosCode	Get or set the view position for this output on the Monitor Card. This attribute will only show when there is a Monitor Card in the system.
AudioBars	Slot<n>.Out<n>.AudioBars	Integer	Slot14.Out1.AudioBars = 4 !Done Slot14.Out1.AudioBars	Get or set the number of audio bars to show for this output on the Monitor Card. The range is 0 to the number of audio channels.
Equipment	Slot<n>.Out<n>.Equipment			Not used.
PhysicalCenterX	Slot<n>.Out<n>.PhysicalCenterX			Not used.
PhysicalCenterY	Slot<n>.Out<n>.PhysicalCenterY			Not used.
PhysicalWidth	Slot<n>.Out<n>.PhysicalWidth			Not used.
PhysicalHeight	Slot<n>.Out<n>.PhysicalHeight			Not used.
PhysicalPixelWidth	Slot<n>.Out<n>.PhysicalPixelWidth			Not used.
PhysicalPixelHeight	Slot<n>.Out<n>.PhysicalPixelHeight			Not used.
PhysicalBezelTop	Slot<n>.Out<n>.PhysicalBezelTop			Not used.
PhysicalBezelBottom	Slot<n>.Out<n>.PhysicalBezelBottom			Not used.
PhysicalBezelLeft	Slot<n>.Out<n>.PhysicalBezelLeft			Not used.
PhysicalBezelRight	Slot<n>.Out<n>.PhysicalBezelRight			Not used.
InsList	Slot<n>.Out<n>.InsList	List	Slot14.Out1.InsList = NULL !Done Slot14.Out1.InsList	Read only. Get or set the list of inputs routed to this output.

Property Name	Syntax	Type	Example	Description
CutToBlack	Slot<n>.Out<n>.CutToBlack	Boolean	Slot14.Out1.CutToBlack = Off !Done Slot14.Out1.CutToBlack	Get or set the output to black. When setting multiple outputs to black it is recommended to surround them with startbatch() endbatch() to synchronise output blanking
Resolutions	Slot<n>	List	Slot14.Resolutions.Resolution1 = <...> Slot14.Resolutions.Resolution2 = <...> ... Slot14.Resolutions.Resolution1000 = <...> Slot14.Resolutions.Resolution1001 = <...> Slot14.Resolutions.Resolution1002 = <...> Slot14.Resolutions.Resolution1003 = <...> Slot14.Resolutions.Resolution1004 = <...> Slot14.Resolutions.Resolution1005 = <...> Slot14.Resolutions.Resolution1006 = <...> Slot14.Resolutions.Resolution1007 = <...> Slot14.Resolutions.Resolution1008 = <...> Slot14.Resolutions.Resolution1009 = <...> !Done Slot14.Resolutions	List the properties for a Resolution where <n> is the number of the Resolution. Note that Resolution1000 to Resolution1009 are Custom Resolutions.
Resolution<n>	Slot<n>.Resolutions.Resolution<n>	List	Slot14.Resolutions.Resolution1.Name = 640x480p60 Slot14.Resolutions.Resolution1.Aspect = 4:3 Slot14.Resolutions.Resolution1.CanFramelock = No !Done Slot14.Resolutions.Resolution1	List the properties of the selected resolution.
Name	Slot<n>.Resolutions.Resolution<n>.Name	String	Slot14.Resolutions.Resolution1.Name = 640x480p60 !Done Slot14.Resolutions.Resolution1.Name	Read only. Get the name of this resolution.
Aspect	Slot<n>.Resolutions.Resolution<n>.Aspect	AspectRatio	Slot14.Resolutions.Resolution1.Aspect = 4:3 !Done Slot14.Resolutions.Resolution1.Aspect	Read only. Get the aspect ratio of this resolution. Used assist to in the signal conversion when an input and the output have different aspect ratios.
CanFramelock	Slot<n>.Resolutions.Resolution<n>.CanFramelock			Not used.

Methods

Command	Syntax	Type	Example	Description
PhaseRetrain	Slot<n>.PhaseRetrain()	void	// Module 14 phase :-----:....., centres at 27, 27 (27). !Done Slot14.PhaseRetrain()	Initiate a Phase retrain for this slot
Module_Resolutions	Slot<n>.Module_Resolutions()	List	640x480p60;4:3; 640x480p72;4:3; ... Empty1000;4:3; Empty1001;4:3; Empty1002;4:3; Empty1003;4:3; Empty1004;4:3; Empty1005;4:3; Empty1006;4:3; Empty1007;4:3; Empty1008;4:3; Empty1009;4:3; !Done Slot14.Module_Resolutions()	List all of the supported resolutions for this slot. Custom resolutions will appear at the end of the list. The list is semicolon separated.
ForceLinkRefresh	Slot<n>.Out<n>.ForceLinkRefresh()	Void	Slot14.Out1.ForceLinkRefresh() !Done Slot14.Out1.ForceLinkRefresh()	Reset the connection to the display.

HDBaseT Output Module

It is possible to use Slot<n>.Out<n> and S<n>O<n> in place of Slots.Slot<n>.Out<n>.

Properties

Property Name	Syntax	Type	Example	Description
Slot<n>	Slot<n>	List	Slot15.Cardtype = HDBASET 2-out Slot15.Carddata = <No Value> Slot15.Out1 = <...> Slot15.Out2 = <...> Slot15.PhaseRetrain() Slot15.Module_Resolutions() Slot15.Resolutions = <...> !Done Slot15	List the properties of the card in this slot or "NO CARD" if the slot is empty.
Cardtype	Slot<n>.Cardtype	CardTypeEnum	Slot15.Cardtype = HDBASET 2-out !Done Slot15.Cardtype	Read-only. Get the type of the card in this slot
CardData	Slot<n>.Carddata			Not used.
Out<n>	Slot<n>.Out<n>	List	Slot15.Out1.FullName = Out1 Slot15.Out1.Status = UNKNOWN Slot15.Out1.Alias = s15o1 Slot15.Out1.AspectChoice = 4:3 Slot15.Out1.DisplayType = Monitor Slot15.Out1.Resolution = 1280x720p60 Slot15.Out1.DefaultLoRes = 720x576i50 Slot15.Out1.Width = 1280 Slot15.Out1.Height = 720 Slot15.Out1.Field_Rate = 60.00 Slot15.Out1.Frame_ip = p Slot15.Out1.AnalogType = RGBHV Slot15.Out1.ColourScale = Auto Slot15.Out1.GenlockSource = NULL Slot15.Out1.Genlock = Off Slot15.Out1.RawMatrixSwitch = Off Slot15.Out1.Audio = Off Slot15.Out1.AudOutA = NULL Slot15.Out1.AudOutB = NULL Slot15.Out1.AudOutC = NULL	List the properties for an Output on the given Slot. Where Out<n> is the output on the card.

Property Name	Syntax	Type	Example	Description
			Slot15.Out1.AudOutD = NULL Slot15.Out1.ForceLinkRefresh() Slot15.Out1.HDCP_Active = Active Slot15.Out1.HDCP_Downstream = HoldOn Slot15.Out1.HDMI = Found Slot15.Out1.Layout = Layout4 Slot15.Out1.WidthInLayout = 1024 Slot15.Out1.HeightInLayout = 768 Slot15.Out1.LayoutXCentre = 0 Slot15.Out1.LayoutYCentre = 0 Slot15.Out1.RotateOutDeg = 0 Slot15.Out1.HFlip = Off Slot15.Out1.VFlip = Off Slot15.Out1.GammaRed = 1 Slot15.Out1.GammaGreen = 1 Slot15.Out1.GammaBlue = 1 Slot15.Out1.SCurve = 1 Slot15.Out1.EdgeBlend_Mode = Off Slot15.Out1.OuterGrid = Off Slot15.Out1.InnerGrid = Off Slot15.Out1.LeftOverlap = 80 Slot15.Out1.RightOverlap = 80 Slot15.Out1.TopOverlap = 80 Slot15.Out1.BottomOverlap = 80 Slot15.Out1.LeftEBPos = -511 Slot15.Out1.RightEBPos = 511 Slot15.Out1.TopEBPos = -383 Slot15.Out1.BottomEBPos = 383 Slot15.Out1.Centre_BB = 0 Slot15.Out1.Left_BB = 0 Slot15.Out1.Right_BB = 0 Slot15.Out1.Top_BB = 0 Slot15.Out1.Bottom_BB = 0 Slot15.Out1.ProjectorWidthDeg = 30 Slot15.Out1.ProjectorHeightDeg = 30	

Property Name	Syntax	Type	Example	Description
			Slot15.Out1.KeystoneXDeg = 0 Slot15.Out1.KeystoneYDeg = 0 Slot15.Out1.WarpTable_Filename = Slot15.Out1.WarpTable = 0 Slot15.Out1.EDID_Filename = Slot15.Out1.View = MonitorViews.View3 Slot15.Out1.ViewPosCode = 18 Slot15.Out1.AudioBars = 4 Slot15.Out1.Equipment = Slot15.Out1.PhysicalCenterX = 0 Slot15.Out1.PhysicalCenterY = 0 Slot15.Out1.PhysicalWidth = 0 Slot15.Out1.PhysicalHeight = 0 Slot15.Out1.PhysicalPixelWidth = 0 Slot15.Out1.PhysicalPixelHeight = 0 Slot15.Out1.PhysicalBezelTop = 0 Slot15.Out1.PhysicalBezelBottom = 0 Slot15.Out1.PhysicalBezelLeft = 0 Slot15.Out1.PhysicalBezelRight = 0 Slot15.Out1.InsList = Slot3.In1 Slot15.Out1.CutToBlack = Off Slot15.Out1.HDBaseT = <...> !Done Slot15.Out1	
FullName	Slot<n>.Out<n>.FullName	String	Slot15.Out1.FullName = Out1 !Done Slot15.Out1.FullName	Read-only. Get the full name of the Window
Status	Slot<n>.Out<n>.Status	StatusEnum	Slot15.Out1.Status = UNKNOWN !Done Slot15.Out1.Status	Read-only. Get the status of the output
Alias	Slot<n>.Out<n>.Alias	String	Slot15.Out1.Alias = s15o1 !Done Slot15.Out1.Alias	Get or set the Alias name for this output.
AspectChoice	Slot<n>.Out<n>.AspectChoice	AspectRatio	Slot15.Out1.AspectChoice = 4:3 !Done Slot15.Out1.AspectChoice	Get or set the aspect ratio for this output.
DisplayType	Slot<n>.Out<n>.DisplayType	DisplayType	Slot15.Out1.DisplayType = Monitor !Done Slot15.Out1.DisplayType	Get or set the type of display connected to this output.

Property Name	Syntax	Type	Example	Description
Resolution	Slot<n>.Out<n>.Resolution	Resolution	Slot15.Out1.Resolution = 1280x720p60 !Done Slot15.Out1.Resolution	Get or set the resolution to use on this output. This must be the name of a valid resolution. See Resources Resolutions on page 33 above.
DefaultLoRes	Slot<n>.Out<n>.DefaultLoRes	Resolution	Slot15.Out1.DefaultLoRes = 720x576i50 !Done Slot15.Out1.DefaultLoRes	Get or set the resolution to use on this output when HDCP is requested by the source but the display failed HDCP negotiation. This must be the name of a valid resolution. See Resources Resolutions on page 33 above.
Width	Slot<n>.Out<n>.Width	Integer	Slot15.Out1.Width = 1280 !Done Slot15.Out1.Width	Read-only. Get the width of this output based on the select resolution.
Height	Slot<n>.Out<n>.Height	Integer	Slot15.Out1.Height = 720 !Done Slot15.Out1.Height	Read-only. Get the height of this output based on the select resolution.
Field_Rate	Slot<n>.Out<n>.Field_Rate	String	Slot15.Out1.Field_Rate = 60.00 !Done Slot15.Out1.Field_Rate	Read-only. Get the field rate for this output based on the select resolution.
Frame_ip	Slot<n>.Out<n>.Frame_ip	FrameType	Slot15.Out1.Frame_ip = p !Done Slot15.Out1.Frame_ip	Read-only. Get the frame type for this output based on the select resolution.
AnalogType	Slot<n>.Out<n>.AnalogType	AnalogType	Slot15.Out1.AnalogType = RGBHV !Done Slot15.Out1.AnalogType	Get or set the type of analog signal to use on this output.
ColourScale	Slot<n>.Out<n>.ColourScale	ColourScale	Slot15.Out1.ColourScale = Auto !Done Slot15.Out1.ColourScale	Get or set the color scale to use on this output..
GenlockSource	Slot<n>.Out<n>.GenlockSource	Input	Slot15.Out1.GenlockSource = NULL !Done Slot15.Out1.GenlockSource	Get or set the Input to be used as the genlock source for the Output. If no Genlock is to be use then the value is to be NULL.
Genlock	Slot<n>.Out<n>.Genlock	GenlockStat us	Slot15.Out1.Genlock = Off !Done Slot15.Out1.Genlock	Read-only. Get the status of genlock for this output.

Property Name	Syntax	Type	Example	Description
RawMatrixSwitch	Slot<n>.Out<n>.RawMatrixSwitch	Boolean	Slot15.Out1.RawMatrixSwitch = Off !Done Slot15.Out1.RawMatrixSwitch	Get or set the input switching mode: Off = fade though black On = freeze and cut
Audio	Slot<n>.Out<n>.Audio	FoundOff	Slot15.Out1.Audio = Off !Done Slot15.Out1.Audio	Read only. Get if there is audio available for this input.
AudOutA	Slot<n>.Out<n>.AudOutA	String	Slot15.Out1.AudOutA = NULL !Done Slot15.Out1.AudOutA	Read only. Defines the audio channel output for channel A
AudOutB	Slot<n>.Out<n>.AudOutB	String	Slot15.Out1.AudOutB = NULL !Done Slot15.Out1.AudOutB	Defines the audio channel output for channel B
AudOutC	Slot<n>.Out<n>.AudOutC	String	Slot15.Out1.AudOutC = NULL !Done Slot15.Out1.AudOutC	Defines the audio channel output for channel C
AudOutD	Slot<n>.Out<n>.AudOutD	String	Slot15.Out1.AudOutD = NULL !Done Slot15.Out1.AudOutD	Defines the audio channel output for channel D
HDCP_Active	Slot<n>.Out<n>.HDCP_Active	Boolean	Slot15.Out1.HDCP_Active = Off !Done Slot15.Out1.HDCP_Active	Read only. Get the HDCP status of this output.
HDCP_Downstream	Slot<n>.Out<n>.HDCP_Downstream	HDCPDownstream	Slot15.Out1.HDCP_Downstream = HoldOn !Done Slot15.Out1.HDCP_Downstream	Get or set the downstream HDCP mode.
HDMI	Slot<n>.Out<n>.HDMI	FoundNot	Slot15.Out1.HDMI = Found !Done Slot15.Out1.HDMI	Read-only. Get the detected HDMI status.
Layout	Slot<n>.Out<n>.Layout			Not used.
WidthInLayout	Slot<n>.Out<n>.WidthInLayout			Not used.
HeightInLayout	Slot<n>.Out<n>.HeightInLayout			Not used.
LayoutXCentre	Slot<n>.Out<n>.LayoutXCentre			Not used.
LayoutYCentre	Slot<n>.Out<n>.LayoutYCentre			Not used.
RotateOutDeg	Slot<n>.Out<n>.RotateOutDeg			Not used.
HFlip	Slot<n>.Out<n>.HFlip			Not used.
VFlip	Slot<n>.Out<n>.VFlip			Not used.
GammaRed	Slot<n>.Out<n>.GammaRed	Number	Slot15.Out1.GammaRed = 1 !Done Slot15.Out1.GammaRed	Get or set the red gamma value for this output Range: 0.30 to 2.00
GammaGreen	Slot<n>.Out<n>.GammaGreen	Number	Slot15.Out1.GammaGreen = 1 !Done Slot15.Out1.GammaGreen	Get or set the green gamma value for this output Range: 0.30 to 2.00

Property Name	Syntax	Type	Example	Description
GammaBlue	Slot<n>.Out<n>.GammaBlue	Number	Slot15.Out1.GammaBlue = 1 !Done Slot15.Out1.GammaBlue	Get or set the blue gamma value for this output Range: 0.30 to 2.00
SCurve	Slot<n>.Out<n>.SCurve	Number	Slot15.Out1.SCure = 1 !Done Slot15.Out1.SCurve	Get or set the SCurve value for this output. (brightness curve) Range: 0.30 to 2.00
EdgeBlend_Mode	Slot<n>.Out<n>.EdgeBlend_Mode			Not used.
OuterGrid	Slot<n>.Out<n>.OuterGrid			Not used.
InnerGrid	Slot<n>.Out<n>.InnerGrid			Not used.
LeftOverlap	Slot<n>.Out<n>.LeftOverlap			Not used.
RightOverlap	Slot<n>.Out<n>.RightOverlap			Not used.
TopOverlap	Slot<n>.Out<n>.TopOverlap			Not used.
BottomOverlap	Slot<n>.Out<n>.BottomOverlap			Not used.
LeftEBPos	Slot<n>.Out<n>.LeftEBPos			Not used.
RightEBPos	Slot<n>.Out<n>.RightEBPos			Not used.
TopEBPos	Slot<n>.Out<n>.TopEBPos			Not used.
BottomEBPos	Slot<n>.Out<n>.BottomEBPos			Not used.
Centre_BB	Slot<n>.Out<n>.Centre_BB			Not used.
Left_BB	Slot<n>.Out<n>.Left_BB			Not used.
Right_BB	Slot<n>.Out<n>.Right_BB			Not used.
Top_BB	Slot<n>.Out<n>.Top_BB			Not used.
Bottom_BB	Slot<n>.Out<n>.Bottom_BB			Not used.
ProjectorWidthDeg	Slot<n>.Out<n>.ProjectorWidthDeg			Not used.
ProjectorHeightDeg	Slot<n>.Out<n>.ProjectorHeightDeg			Not used.
KeystoneXDeg	Slot<n>.Out<n>.KeystoneXDeg			Not used.
KeystoneYDeg	Slot<n>.Out<n>.KeystoneYDeg			Not used.
WarpTable_Filename	Slot<n>.Out<n>.WarpTable_Filename			Not used.
WarpTable	Slot<n>.Out<n>.WarpTable			Not used.
EDID_Filename	Slot<n>.Out<n>.EDID_Filename	String	Slot15.Out1.EDID_Filename = !Done Slot15.Out1.EDID_Filename	Get or set the EDID file in any currently being used for this output.

Property Name	Syntax	Type	Example	Description
View	Slot<n>.Out<n>.View	String	Slot15.Out1.View = MonitorViews.View3 !Done Slot15.Out1.View	This attribute will only show when there is a Monitor Card in the system. Get or set the view to show on the Monitor Card.
ViewPosCode	Slot<n>.Out<n>.ViewPosCode	Integer	Slot15.Out1.ViewPosCode = 18 !Done Slot15.Out1.ViewPosCode	This attribute will only show when there is a Monitor Card in the system. Get or set the view position for this output on the Monitor Card.
AudioBars	Slot<n>.Out<n>.AudioBars	Integer	Slot15.Out1.AudioBars = 4 !Done Slot15.Out1.AudioBars	Get or set the number of audio bars to show for this output on the Monitor Card. The range is 0 to the number of audio channels.
Equipment	Slot<n>.Out<n>.Equipment			Not used.
PhysicalCenterX	Slot<n>.Out<n>.PhysicalCenterX			Not used.
PhysicalCenterY	Slot<n>.Out<n>.PhysicalCenterY			Not used.
PhysicalWidth	Slot<n>.Out<n>.PhysicalWidth			Not used.
PhysicalHeight	Slot<n>.Out<n>.PhysicalHeight			Not used.
PhysicalPixelWidth	Slot<n>.Out<n>.PhysicalPixelWidth			Not used.
PhysicalPixelHeight	Slot<n>.Out<n>.PhysicalPixelHeight			Not used.
PhysicalBezelTop	Slot<n>.Out<n>.PhysicalBezelTop			Not used.
PhysicalBezelBottom	Slot<n>.Out<n>.PhysicalBezelBottom			Not used.
PhysicalBezelLeft	Slot<n>.Out<n>.PhysicalBezelLeft			Not used.
PhysicalBezelRight	Slot<n>.Out<n>.PhysicalBezelRight			Not used.
InsList	Slot<n>.Out<n>.InsList	List	Slot15.Out1.InsList = NULL !Done Slot15.Out1.InsList	Read only. Get or set the list of inputs routed to this output.

Property Name	Syntax	Type	Example	Description
CutToBlack	Slot<n>.Out<n>.CutToBlack	Boolean	Slot15.Out1.CutToBlack = Off !Done Slot15.Out1.CutToBlack	Get or set the output to black. When setting multiple outputs to black it is recommended to surround them with startbatch() endbatch() to synchronise output blanking
HDBaseT	Slot<n>.Out<n>.HDBaseT	List	Slot15.Out1.HDBaseT.CurrentMode = Auto Standard mode Slot15.Out1.HDBaseT.LocalLinkStatus = HDBASE_T_LINK_ON Slot15.Out1.HDBaseT.LocalFwVer = 1.30.37.10 Slot15.Out1.HDBaseT.CableLength = Invalid Slot15.Out1.HDBaseT.LocalHDMIStatus = HDBASE_T_HDMI_HDCP_ON Slot15.Out1.HDBaseT.MaxError = Caution: 1 : 0 : 0 : 0 Slot15.Out1.HDBaseT.RemoteFWVer = 1.30.4.0 Slot15.Out1.HDBaseT.RemoteLinkStatus = HDBASE_T_LINK_ON Slot15.Out1.HDBaseT.RemoteHDMIStatus = HDBASE_T_HDMI_HDCP_ON Slot15.Out1.HDBaseT.LocalLinkReset() Slot15.Out1.HDBaseT.RemoteLinkReset() !Done Slot15.Out1.HDBaseT	List the HDBaseT specific attributes for this card.
CurrentMode	Slot<n>.Out<n>.HDBaseTCurrentMode	HDBaseTStatus	Slot15.Out1.HDBaseT.CurrentMode = Auto Standard mode !Done Slot15.Out1.HDBaseT.CurrentMode	Read only. Get the current HDBaseT status. This comprises of the current configuration and mode.
LocalLinkStatus	Slot<n>.Out<n>.HDBaseTLocalLinkStatus	HDBaseTLink	Slot15.Out1.HDBaseT.LocalLinkStatus = HDBASE_T_LINK_ON !Done Slot15.Out1.HDBaseT.LocalLinkStatus	Read only. Get the status of the local end of the link.
LocalFwVer	Slot<n>.Out<n>.HDBaseTLocalFwVer	String	Slot15.Out1.HDBaseT.LocalFwVer = 1.30.37.10 !Done Slot15.Out1.HDBaseT.LocalFwVer	Read only. Get the version of the HDBaseT firmware in the card.

Property Name	Syntax	Type	Example	Description
CableLength	Slot<n>.Out<n>.HDBaseTCableLength	String	Slot15.Out1.HDBaseT.CableLength = Invalid !Done Slot15.Out1.HDBaseT.CableLength	Read only. Get the link cable length in meters as measured by the card. This may be "Invalid" or a value between 20 and 100. "Invalid," a value outside the range or significantly different from that of the physical cable may indicate a cabling issue.
LocalHDMIStatus	Slot<n>.Out<n>.HDBaseTLocalHDMIStatus	HDBaseTHDMI	Slot15.Out1.HDBaseT.LocalHDMIStatus = HDBASE_T_HDMI_HDCP_ON !Done Slot15.Out1.HDBaseT.LocalHDMIStatus	Read only. Get the status of the video connection at the local end of the link.
MaxError	Slot<n>.Out<n>.HDBaseTMaxError	HDBaseTErr or	Slot15.Out1.HDBaseT.MaxError = Caution: 255 : 255 : 255 : 255 !Done Slot15.Out1.HDBaseT.MaxError	Read only. Get the error statistics.
RemoteFWVer	Slot<n>.Out<n>.HDBaseTRemoteFWVer	String	Slot15.Out1.HDBaseT.RemoteFWVer = 1.30.4.0 !Done Slot15.Out1.HDBaseT.RemoteFWVer	Read only. Get the version of the HDBaseT firmware in the remote device.
RemoteLinkStatus	Slot<n>.Out<n>.HDBaseTRemoteLinkStatus	HDBaseTLink	Slot15.Out1.HDBaseT.RemoteLinkStatus = HDBASE_T_LINK_ON !Done Slot15.Out1.HDBaseT.RemoteLinkStatus	Read only. Get the status of the remote end of the link.
RemoteHDMIStatus	Slot<n>.Out<n>.HDBaseTRemoteHDMIStatus	HDBaseTHDMI	Slot15.Out1.HDBaseT.RemoteHDMIStatus = HDBASE_T_HDMI_HDCP_ON !Done Slot15.Out1.HDBaseT.RemoteHDMIStatus	Read only. Get the status of the video connection at the remote end of the link.

Property Name	Syntax	Type	Example	Description
Resolutions	Slot<n>	List	Slot15.Resolutions.Resolution1 = <...> Slot15.Resolutions.Resolution2 = <...> ... Slot15.Resolutions.Resolution1000 = <...> Slot15.Resolutions.Resolution1001 = <...> Slot15.Resolutions.Resolution1002 = <...> Slot15.Resolutions.Resolution1003 = <...> Slot15.Resolutions.Resolution1004 = <...> Slot15.Resolutions.Resolution1005 = <...> Slot15.Resolutions.Resolution1006 = <...> Slot15.Resolutions.Resolution1007 = <...> Slot15.Resolutions.Resolution1008 = <...> Slot15.Resolutions.Resolution1009 = <...> !Done Slot15.Resolutions	List the properties for a Resolution. Where <n> is the number of the Resolution. Note that Resolution1000 to Resolution1009 are Custom Resolutions.
Resolution<n>	Slot<n>.Resolutions.Resolution<n>	List	Slot15.Resolutions.Resolution1.Name = 640x480p60 Slot15.Resolutions.Resolution1.Aspect = 4:3 Slot15.Resolutions.Resolution1.CanFramelock = No !Done Slot15.Resolutions.Resolution1	List the properties of the selected resolution.
Name	Slot<n>.Resolutions.Resolution<n>.Name	String	Slot15.Resolutions.Resolution1.Name = 640x480p60 !Done Slot15.Resolutions.Resolution1.Name	Read only. Get the name of this resolution.
Aspect	Slot<n>.Resolutions.Resolution<n>.Aspect	AspectRatio	Slot15.Resolutions.Resolution1.Aspect = 4:3 !Done Slot15.Resolutions.Resolution1.Aspect	Read only. Get or set the aspect ratio of this resolution Used assist in the signal conversion when an input and the output have different aspect ratio.
CanFramelock	Slot<n>.Resolutions.Resolution<n>.CanFramelock			Not used.

Methods

Command	Syntax	Type	Example	Description
PhaseRetrain	Slot<n>.PhaseRetrain()	void	// Module 15 phase -----R:.....R---, centres at 23, 23 (23). !Done Slot15.PhaseRetrain()	Initiates a Phase retrain for this slot
Module_Resolutions	Slot<n>.Module_Resolutions()	List	640x480p60;4:3; 640x480p72;4:3; ... Empty1001;4:3; Empty1002;4:3; Empty1003;4:3; Empty1004;4:3; Empty1005;4:3; Empty1006;4:3; Empty1007;4:3; Empty1008;4:3; Empty1009;4:3; !Done Slot15.Module_Resolutions()	List all of the supported resolutions for this slot. Custom resolutions will appear at the end of the list. The list is semicolon separated.
LocalLinkReset	Slot<n>.Out<n>.HDBaseT.LocalLinkReset()	Void	Slot15.Out1.HDBaseT.LocalLinkReset() !Done Slot15.Out1.HDBaseT.LocalLinkReset()	Reset the local end of the link.
RemoteLinkReset()	Slot<n>.Out<n>.HDBaseT.RemoteLinkReset()	Void	Slot15.Out1.HDBaseT.RemoteLinkReset() !Done Slot15.Out1.HDBaseT.RemoteLinkReset()	Reset the remote end of the link.

Audio Module

It is possible to use Slot<n>.Out<n> and S<n>O<n> in place of Slots.Slot<n>.Out<n> and Slot<n>.Out<n> and S<n>O<n> in place of Slots.Slot<n>.Out<n>.

Properties

Property Name	Syntax	Type	Example	Description
Slot<n>	Slot<n>	List	Slot1.Cardtype = Audio 8-in 8-out Slot1.Carddata = <No Value> Slot1.In1 = <...> Slot1.In2 = <...> Slot1.In3 = <...> Slot1.In4 = <...> Slot1.In5 = <...> Slot1.In6 = <...> Slot1.In7 = <...> Slot1.In8 = <...> Slot1.Out1 = <...> Slot1.Out2 = <...> Slot1.Out3 = <...> Slot1.Out4 = <...> Slot1.Out5 = <...> Slot1.Out6 = <...> Slot1.Out7 = <...> Slot1.Out8 = <...> !Done Slot1	List the properties of the card in this slot or "NO CARD" if the slot is empty.
Cardtype	Slot<n>.Cardtype	CardTypeEnum	Slot1.Cardtype = Audio 8-in 8-out !Done Slot1.Cardtype	Read-only. Get the type of the card in this slot.
CardData	Slot<n>.Carddata			Not used.
In<n>	Slot<n>.In<n>	List	Slot1.In1.FullName = In1 Slot1.In1.Status = Slot1.In1.Alias = s1i1 Slot1.In1.AudInA = NULL !Done Slot1.In1	List the properties for an Input on this Slot. Where In<n> is the input on the card.
FullName	Slot<n>.In<n>.FullName	String	Slot1.In1.FullName = In1 !Done Slot1.In1.FullName	Read-only. Get the full name of the Window
Status	Slot<n>.In<n>.Status	StatusEnum	Slot1.In2.Status = !Done Slot1.In2.Status	Read-only. Get the status of the input.

Property Name	Syntax	Type	Example	Description
Alias	Slot<n>.In<n>.Alias	String	Slot1.In1.Alias = s1i1 !Done Slot1.In1.Alias	Get or set the Alias name for this input.
AudInA	Slot<n>.In<n>.AudInA	String	Slot1.In1.AudInA = NULL !Done Slot1.In1.AudInA	Read only. Defines the audio channel input for channel A
Out<n>	Slot<n>.Out<n>	List	Slot1.Out1.FullName = Out1 Slot1.Out1.Status = Slot1.Out1.Alias = s1o1 Slot1.Out1.AudOutA = NULL !Done Slot1.Out1	List the properties for an Output on this Slot. Where Out<n> is the output on the card.
FullName	Slot<n>.Out<n>.FullName	String	Slot1.Out1.FullName = Out1 !Done Slot1.Out1.FullName	Read-only. Get the full name of the Window
Status	Slot<n>.Out<n>.Status	StatusEnum	Slot1.Out1.Status = !Done Slot1.Out1.Status	Read-only. Get the status of the output
Alias	Slot<n>.Out<n>.Alias	String	Slot1.Out1.Alias = s1o1 !Done Slot1.Out1.Alias	Get or set the Alias name for this output.
AudOutA	Slot<n>.Out<n>.AudOutA	String	Slot1.Out1.AudOutA = NULL !Done Slot1.Out1.AudOutA	Read only. Defines the audio channel output for channel A

HDBASE-T Input Module

This section covers the following modules:

AK67 2 input hdbase-t module

It is possible to use Slot<n>.In<n> and S<n>I<n> in place of Slots.Slot<n>.In<n>.

Properties

Property Name	Syntax	Type	Example	Description
Slot<n>	Slot<n>	List	Slot3.Cardtype = DVI_U 2-in Slot3.Carldata = <No Value> Slot3.In1 = <...> Slot3.In2 = <...> Slot3.PhaseRetrain() Slot3.Module_Resolutions() !Done Slot3	List all of the properties of the card in this slot or "NO CARD" if the slot is empty.
Cardtype	Slot<n>.Cardtype	CardTypeEnum	Slot3.Cardtype = DVI_U 2-in !Done Slot3.Cardtype	Read-only. Get the type of the card in this slot
In<n>	Slot<n>.In<n>	List	Slot3.In1.FullName = In1 Slot3.In1.Status = OK Slot3.In1.Alias = s3i1 Slot3.In1.WindowList = Window1,Window2 Slot3.In1.AspectChoice = 4:3 Slot3.In1.Brightness = 0 Slot3.In1.Contrast = 100 Slot3.In1.ColourScale = Auto Slot3.In1.TPG = Off Slot3.In1.Set_Resolution = 640x480p60 Slot3.In1.Measured_Resolution = 640x480p60 Slot3.In1.Measured_Width = 640 Slot3.In1.Measured_Height = 480 Slot3.In1.Measured_Field_Rate = 60 Slot3.In1.Measured_VTotal = 525 Slot3.In1.Measured_Frame_ip = p Slot3.In1.EDID_Filename = s3i1.edd Slot3.In1.ForceLinkRefresh()	List the properties for an Input on the given Slot. Where In<n> is the input on the card.

Property Name	Syntax	Type	Example	Description
			Slot3.In1.LeftCrop = 0 Slot3.In1.RightCrop = 0 Slot3.In1.TopCrop = 0 Slot3.In1.BottomCrop = 0 Slot3.In1.AnH_Offset = 0 Slot3.In1.AnV_Offset = 0 Slot3.In1.OnSrcLossColour = Blue Slot3.In1.HDCP_Enabled = Supported Slot3.In1.HDCP_Required = Off Slot3.In1.HDMI = Found Slot3.In1.Audio = Found Slot3.In1.AudInA = NULL Slot3.In1.AudInB = NULL Slot3.In1.AudInC = NULL Slot3.In1.AudInD = NULL Slot3.In1.AFVChoiceA = Slot3.In1.AudInA Slot3.In1.AFVChoiceB = Slot3.In1.AudInB Slot3.In1.AFVChoiceC = Slot3.In1.AudInC Slot3.In1.AFVChoiceD = Slot3.In1.AudInD Slot3.In1.View = NULL Slot3.In1.ViewPosCode = 0 Slot3.In1.AudioBars = 4 Slot3.In1.PreviewVideoType = 0 Slot3.In1.Equipment = Slot3.In1.CanFramelockTo = No Slot3.In1.dll = 16 Slot3.In1.imm = Yes !Done Slot3.In1	
FullName	Slot<n>.In<n>.FullName	String	Slot3.In1.FullName = In1 !Done Slot3.In1.FullName	Read-only. Get the full name of the Window
Status	Slot<n>.In<n>.Status	StatusEnum	Slot3.In1.Status = OK !Done Slot3.In1.Status	Read-only. Get the status of the input.

Property Name	Syntax	Type	Example	Description
Alias	Slot<n>.In<n>.Alias	String	Slot3.In1.Alias = s3i1 !Done Slot3.In1.Alias	Get or set the Alias name for this input. Warning it is possible to set this value to that used by another input, in which case the other value will be set to NULL.
WindowList	Slot<n>.In<n>.WindowList	String	Slot3.In1.WindowList = Window1 !Done Slot3.In1.WindowList	Read only. Get the window that the slot is routed to.
AspectChoice	Slot<n>.In<n>.AspectChoice	AspectRatio	Slot3.In1.AspectChoice = 4:3 !Done Slot3.In1.AspectChoice = 4:3	Get or set the aspect ratio for this input
Brightness	Slot<n>.In<n>.Brightness	Integer	Slot3.In1.Brightness = 0 !Done Slot3.In1.Brightness	Get or set the brightness adjustment for this input. Valid range is from -30 to 30
Contrast	Slot<n>.In<n>.Contrast	Percentage	Slot3.In1.Contrast = 100 !Done Slot3.In1.Contrast	Get or set the contrast adjustment for the Input. Valid range is from 30% to 130%
ColourScale	Slot<n>.In<n>.ColourScale	ColourScale	Slot3.In1.ColourScale = Auto !Done Slot3.In1.ColourScale	Get or set the colour scale for this input.
TPG	Slot<n>.In<n>.TPG	Boolean	Slot3.In1.TPG = TPG1 !Done Slot3.In1.TPG = TPG1	Get or set to use the internal Test Pattern Generator (TPG1) for this input. Options are "Off" or "TPG1".
Set_Resolution	Slot<n>.In<n>.Set_Resolution	Resolution	Slot3.In1.Set_Resolution = 640x480p60 !Done Slot3.In1.Set_Resolution	Read-only. Get the current resolution set for this input.
Measured_Resolution	Slot<n>.In<n>.Measured_Resolution	Resolution	Slot3.In1.Measured_Resolution = 640x480p60 !Done Slot3.In1.Measured_Resolution	Read-only. Get the resolution being read from this Input.
Measured_Width	Slot<n>.In<n>.Measured_Width	Integer	Slot3.In1.Measured_Width = 640 !Done Slot3.In1.Measured_Width	Read-only. Get the width of the resolution being read from this input.
Measured_Height	Slot<n>.In<n>.Measured_Height	Integer	Slot3.In1.Measured_Height = 480 !Done Slot3.In1.Measured_Height	Read-only. Get the measured height of the resolution being read from this input.
Measured_Field_Rate	Slot<n>.In<n>.Measured_Field_Rate	Integer	Slot3.In1.Measured_Field_Rate = 60 !Done Slot3.In1.Measured_Field_Rate	Read-only. Get the measured field rate of the resolution being read from this input.

Property Name	Syntax	Type	Example	Description
Measured_VTotal	Slot<n>.In<n>.Measured_VTotal	Integer	Slot3.In1.Measured_VTotal = 525 !Done Slot3.In1.Measured_VTotal	Read-only. Get the measured total vertical lines of the resolution being read from this input.
Measure_Frame_ip	Slot<n>.In<n>.Measure_Frame_ip	FrameType	Slot3.In1.Measured_Frame_ip = p !Done Slot3.In1.Measured_Frame_ip	Read-only. Get the measured frame type of the resolution being read from this input.
EDID_Filename	Slot<n>.In<n>.EDID_Filename	String	Slot3.In1.EDID_Filename = s3i1.edd !Done Slot3.In1.EDID_Filename	Get or set the EDID file currently being used for this input.
LeftCrop	Slot<n>.In<n>.LeftCrop	Integer	Slot3.In1.LeftCrop = 0 !Done Slot3.In1.LeftCrop	Get or set the amount of left crop to be applied to this input.
RightCrop	Slot<n>.In<n>.RightCrop	Integer	Slot3.In1.RightCrop = 0 !Done Slot3.In1.RightCrop	Get or set the amount of right crop to be applied to this input.
TopCrop	Slot<n>.In<n>.TopCrop	Integer	Slot3.In1.TopCrop = 0 !Done Slot3.In1.TopCrop	Get or set the amount of top crop to be applied to this input.
BottomCrop	Slot<n>.In<n>.BottomCrop	Integer	Slot3.In1.BottomCrop = 0 !Done Slot3.In1.BottomCrop	Get or set the amount of bottom crop to be applied to this input.
AnH_Offset	Slot<n>.In<n>.AnH_Offset	Integer	Slot3.In1.AnH_Offset = 0 !Done Slot3.In1.AnH_Offset	Adjust the horizontal position of component analog input, measured in lines. Range from -100 to 100.
AnV_Offset	Slot<n>.In<n>.AnV_Offset	Integer	Slot6.In1.AnV_Offset = 0 !Done Slot6.In1.AnV_Offset	Adjust the vertical position of component analog input, measured in lines. Range from -100 to 100.
OnSrcLossColor	Slot<n>.In<n>.OnSrcLossColor	SrcLossColor	Slot6.In1.OnSrcLossColor = Blue !Done Slot6.In1.OnSrcLossColor	Get or set the colour to be displayed when the input source is lost.
HDCP_Enabled	Slot<n>.In<n>.HDCP_Enabled	HDCPSup	Slot3.In1.HDCP_Enabled = Supported !Done Slot3.In1.HDCP_Enabled	Get or set if HDCP is enabled for this source
HDCP_Required	Slot<n>.In<n>.HDCP_Required	HDCPReq	Slot3.In1.HDCP_Required = Off !Done Slot3.In1.HDCP_Required	Read-only. Get the HDCP capability of the input source.
HDMI	Slot<n>.In<n>.HDMI	FoundNot	Slot3.In1.HDMI = Found !Done Slot3.In1.HDMI	Read-only. Get the detected HDMI status.

Property Name	Syntax	Type	Example	Description
Audio	Slot<n>.In<n>.Audio	FoundOff	Slot3.in1.Audio = Found !Done Slot3.in1.Audio	Read only. Get if audio is available for this input.
AudInA	Slot<n>.In<n>.AudInA	String	Slot3.In1.AudInA = NULL !Done Slot3.In1.AudInA	Read only. Defines the audio channel input for channel A
AudInB	Slot<n>.In<n>.AudInB	String	Slot3.In1.AudInB = NULL !Done Slot3.In1.AudInB	Defines the audio channel input for channel B
AudInC	Slot<n>.In<n>.AudInC	String	Slot3.In1.AudInC = NULL !Done Slot3.In1.AudInC	Defines the audio channel input for channel C
AudInD	Slot<n>.In<n>.AudInD	String	Slot3.In1.AudInD = NULL !Done Slot3.In1.AudInD	Defines the audio channel input for channel D
AFVChoiceA	Slot<n>.In<n>.AFVChoiceA	AudiolInput	Slot3.In1.AFVChoiceA = Slot3.In1.AudInA !Done Slot3.In1.AFVChoiceA	Get or set the audio source channel to use in Audio Follow Video mode
AFVChoiceB	Slot<n>.In<n>.AFVChoiceB	AudiolInput	Slot3.In1.AFVChoiceB = Slot3.In1.AudInB !Done Slot3.In1.AFVChoiceB	Get or set the audio source channel to use in Audio Follow Video mode
AFVChoiceC	Slot<n>.In<n>.AFVChoiceC	AudiolInput	Slot3.In1.AFVChoiceC = Slot3.In1.AudInC !Done Slot3.In1.AFVChoiceC	Get or set the audio source channel to use in Audio Follow Video mode
AFVChoiceD	Slot<n>.In<n>.AFVChoiceD	AudiolInput	Slot3.In1.AFVChoiceD = Slot3.In1.AudInD !Done Slot3.In1.AFVChoiceD	Get or set the audio source channel to use in Audio Follow Video mode
View	Slot<n>.Out<n>.View	String	Slots.Slot3.In1.View = NULL !Done Slots.Slot3.In1.View	This attribute will only show when there is a Monitor Card in the system. Get or set the view to show on the Monitor Card.
ViewPosCode	Slot<n>.Out<n>.ViewPosCode	Integer	Slots.Slot3.In1.ViewPosCode = 0 !Done Slots.Slot3.In1.ViewPosCode	This attribute will only show when there is a Monitor Card in the system. Get or set the view position for this output on the Monitor Card.
AudioBars	Slot<n>.In<n>.AudioBars	Integer	Slot3.In1.AudioBars = 4 !Done Slot3.In1.AudioBars	Get or set the number of audio bars to show on the monitorcard screen for this input. The range is 0 to the number of audio channels.

Property Name	Syntax	Type	Example	Description
HDBaseT	Slot<n>.In<n>.HDBaseT	Sub-Menu	Slot1.In1.HDBaseT = <...>	List the HDBaseT specific attributes for this card. See the HDBASE-T Sub-Menu section below.

Routing Commands

Properties

Command	Syntax	Type	Example	Description
Routing	Routing	List	Routing.Windows = <...> Routing.Canvases = <...> Routing.Layouts = <...> Routing.MonitorViews = <...> Routing.Preset = <...> !Done Routing	List the routing commands and properties
Windows	Routing.Windows			Not used.
Canvases	Routing.Canvases			Not used.
Layouts	Routing.Layouts			Not used.

MonitorViews Commands

It is possible to use MonitorViews in place of Routing. MonitorViews and either View<n> or MonitorViews.View<n> in place of Routing. MonitorViews.View<n>.

In View<n> the “<n>” represents the number of the View (for example “1” for View1).

Note that these attributes will only be available if there is a Monitor Card present.

Properties

Property Name	Syntax	Type	Example	Description
MonitorViews	MonitorViews	List	MonitorViews.View1 = <...> MonitorViews.View2 = <...> MonitorViews.View3 = <...> MonitorViews.View4 = <...> MonitorViews.AutoScaling = On MonitorViews.Auto = Off !Done MonitorViews	List of properties and submenus for the Monitor Card routing.
View<n>	View<n>	List	View1.FullName = View1 View1.Status = FREE View1.Alias = NULL View1.Canvas = Canvas1 View1.CanWidth = 896 View1.CanHeight = 512 View1.CanXCentre = -448 View1.CanYCentre = -256 View1.Zorder = 1 View1.RotateDeg = 0 View1.VNum = 34 !Done View1	List the View properties.
FullName	View<n>.FullName	String	View1.FullName = View1 !Done View1.FullName	Get or set the name of this monitor view.
Status	View<n>.Status		View1.Status = FREE !Done View1.Status	Not used.
Alias	View<n>.Alias	String	View1.Alias = NULL !Done View1.Alias	Get or set the alias name for this View
Canvas	View<n>.Canvas	String	View1.Canvas = Canvas1	Get or set the view of a thumbnail.

Property Name	Syntax	Type	Example	Description
			!Done View1.Canvas	
CanWidth	View<n>.CanWidth	Integer	View1.CanWidth = 896 !Done View1.CanWidth	Get or set the width of a thumbnail.
CanHeight	View<n>.CanHeight	Integer	View1.CanHeight = 512 !Done View1.CanHeight	Get or set the height a thumbnail.
CanXCentre	View<n>.CanXCentre	Integer	View1.CanXCentre = -448 !Done View1.CanXCentre	Get or set the horizontal location on screen of a thumbnail.
CanYCentre	View<n>.CanYCentre	Integer	View1.CanYCentre = -256 !Done View1.CanYCentre	Get or set the vertical location on screen of a thumbnail.
Zorder	View<n>.Zorder	Integer	View1.Zorder = 1 !Done View1.Zorder	Get or set the order of the thumbnails.
RotateDeg	View<n>.RotateDeg	Degrees	View1.RotateDeg = 0 !Done View1.RotateDeg	Get or set the rotation of a thumbnail in degrees.
VNum	View<n>.VNum	Integer	View1.VNum = 34 !Done View1.VNum	Get or set the thumbnail grid layout. The number is calculated from the following formula: VNum = <x> * 16 + <y> For example: 1x1 grid = 1 * 16 + 1 = 17 2x2 grid = 2 * 16 + 2 = 34 2x1 grid = 2 * 16 + 1 = 33 4x4 grid = 4 * 16 + 4 = 68
AutoScaling	MonitorViews.AutoScaling	Boolean	MonitorViews.AutoScaling = On !Done MonitorViews.AutoScaling	Get or set automatic scaling of the thumbnails.
Auto	MonitorViews.Auto	Boolean	MonitorViews.Auto = Off !Done MonitorViews.Auto	Get or set automatic ("On") or manual ("Off") configuration of the Monitor Card views.

Preset Commands

It is possible to use Preset in place of Routing.Preset.

Properties

Property Name	Syntax	Type	Example	Description
Preset	Preset	List	Preset.PresetList() Preset.Take = 0 Preset.Read = 0 Preset.Valid = No Preset.NameRead = Preset.CanvasRead = Preset.SeqNumRead = 0 Preset.FlagsRead = 0 Preset.DataRead = <No Value> Preset.SaveRead() Preset.RestoreRead() Preset.RmvPresetFileRead() Preset.SaveAllPresets() Preset.RestoreAllPresets() Preset.RemovePresetFiles() !Done Preset	List of the preset properties.
Take	Preset.Take	Integer	Preset.Take = 0 !Done Preset.Take	Get or set the active preset (by ID number: 1-49) This is the equivalent to Preset.Read followed by Preset.RestoreRead.
Read	Preset.Read	Integer	Preset.Read = 0 !Done Preset.Read	Get or set the preset to be edited (by ID number: 1-49)
Valid	Preset.Valid	Boolean	Preset.Valid = No !Done Preset.Valid	Read-only. Get if the active preset has been saved.
NameRead	Preset.NameRead	String	Preset.NameRead = !Done Preset.NameRead	Get or set the name of the active preset. The name may be up to 19 alphanumeric characters, no spaces.
CanvasRead	Preset.CanvasRead			Not used.
SeqNumRead	Preset.SeqNumRead			Not used.
FlagsRead	Preset.FlagsRead			Not used.
DataRead	Preset.DataRead			Not used.

Methods

Command	Syntax	Type	Example	Description
PresetList	Preset.PresetList()	List	Routing.Preset.PresetList[0]=preset0, !Done Preset.PresetList()	List all the valid presets by ID. The result will contain the preset name and Canvas name if any.
SaveRead	Preset.SaveRead()	Void	// Preset(s) saved. !Done Preset.SaveRead()	Save the active preset from the live data (RAM) to the on-chip memory.
RestoreRead	Preset.RestoreRead()	Void	// Preset(s) restored. !Done Preset.RestoreRead()	Restore the active preset from the on-chip memory to the live data (RAM).
RmvPresetFileRead	Preset.RmvPresetFileRead()	Void	// Preset(s) cleared. !Done Preset.RmvPresetFileRead()	Clear the active preset from the on-chip memory.
SaveAllPresets	Preset.SaveAllPresets()	Void	// Preset(s) saved. !Done Preset.SaveAllPresets()	Deprecated Save all presets to the on-chip memory. Redundant as RAM and on-chip memory are kept synchronized.
RestoreAllPresets	Preset.RestoreAllPresets()	Void	// Preset(s) restored. !Done Preset.RestoreAllPresets()	Deprecated Restore all presets from the on-chip memory. Redundant as RAM and on-chip memory are kept synchronized.
RemovePresetFiles	Preset.RemovePresetFiles()	Void	// Preset(s) cleared. !Done Preset.RemovePresetFiles()	Clear all presets from the on-chip memory.

Custom Types

Name	Values
AnalogType	RGBHV, RGBs, RGsB, YCbCr/YPbPr
AspectRatio	16:9, 4:3, 5:4, 16:10, 5:3, 1:1, 16:6
AudiInput	Slot<n>.In<n>.AudIn<X>, NULL – Where <n> is a number and <X> is a letter.
Boolean	“On” and “Off” or “Yes” and “No”
ColourScale	Auto, Black, YUV, RGB, YUV_601, YUV_709
DisplayType	Monitor, Projector, None
FoundNot	Found, Not_Found
FoundOff	Found, Off
FrameLockStatus	Off, Locked, Unlocked
FrameType	I Interlaced P Progressive
GenlockStatus	Off, Locked
HDBaseTError	The quality of the HDBaseT link. Max error Status: Valid: <n> : <n> : <n> : <n> The error statistics have stabilised. Caution: <n> : <n> : <n> : <n> The error statistics have not yet stabilised. Four channels of error statistics. If valid, the lower the number the better the quality of the link For example: Valid: 16 : 15 : 15 : 16
HDBaseTHDMI	The current state of the Video transfer: HDBASE_T_HDMI_NONE No video is being transmitted over the link. HDBASE_T_HDMI_ON Un-encrypted video is being transmitted over the link. HDBASE_T_HDMI_HDCP_ON Encrypted video is being sent over the link. HDBASE_T_HDMI_INDETERMINATE Warning, unable to read remote status.
HDBaseTLink	Local and remote link status: HDBASE_T_LINK_NONE No link established. HDBASE_T_LINK_ON Link is established. HDBASE_T_LINK_LOW_POWER Link has entered a low power mode. HDBASE_T_LINK_ETHER_ONLY Ethernet only mode. HDBASE_T_LINK_INDETERMINATE An error condition has occurred. Note that the remote link and the local link should normally be expected to be in the same state. A difference would indicate an error condition, or a possible incompatibility between the transmitter and the receiver.

Name	Values
HDBaseTStatus	<p>The status of the HTBaseT module, it consists of a configuration part and a mode part.</p> <p>The current configuration:</p> <ul style="list-style-type: none"> Unknown An error has occurred. Auto The link has auto configured. The expected value. Manual Not supported <p>The current mode:</p> <ul style="list-style-type: none"> Standard mode Default, normal operation. Disconnect Link is inactive. Long reach mode Link is attempting to work over a longer cable. Ethernet fallback Link will pass Ethernet connections but not video. Reserved Link is in a reserved state. This will indicate an error condition. Powerdown 1 The link has entered one of two low power modes Powerdown 2 The link has entered one of two low power modes. HDMI Bypass Link is not being used. Entering this mode will indicate an error of some kind.
HDCPDownstream	<p>Status of the HDCP link:</p> <ul style="list-style-type: none"> HoldOn Keep HDCP active KeepOff De-activate HDCP FollowSource Turns HDCP on or off depending on the source
HDCPReq	Required, Off
HDCPSup	Supported, Off
Polarity	<ul style="list-style-type: none"> N Negative P Positive
Role	Administrator, PowerUser, User, Guest, Test
ScanMode	<ul style="list-style-type: none"> I Interlaced P Progressive
SrcLossColor	Black, Blue, Red, Green, Yellow, Magenta, Cyan, White
StatusEnum	UNKNOWN, OK, INVALID
SystemStatus	Serving, Busy
TestPattern	RGB_100, Black, 8x8_Grid, Dot, 8x8_ChqBrd
TypeChoice	<p>Options for DVI cards:</p> <ul style="list-style-type: none"> DVI, RGBHV, RGsB, YUV, CV, YC <p>Options for SDI cards</p> <ul style="list-style-type: none"> SDI
WindowStatus	FREE, ALLOCATED, IN USE, NULL